

2022-2023 CATALOG

ATTENTION !

END USERS MUST READ AND FOLLOW THIS INFORMATION.

DISTRIBUTORS & OEM'S: PLEASE ENSURE THAT YOUR CUSTOMERS ARE MADE AWARE OF THE FOLLOWING INFORMATION ON THIS PAGE.

- (1) VERIFY THAT BOTH COUPLING'S AND DRAWBAR EYE'S RATED CAPACITIES MEET YOUR APPLICATION(S) REQUIREMENTS.
- (2) DO NOT OVERLOAD COUPLING OR DRAWBAR EYE.
- (3) INSPECT COUPLING, LATCH AND DRAWBAR EYE FOR CRACKS, BENDING DAMAGE OR EXCESSIVE WEAR. DO NOT USE IF ANY OF THESE CONDITIONS EXIST!
- (4) CHECK FOR GAP BETWEEN CLOSED LATCH AND TOP OF HORN OR COUPLING BALL. DO NOT USE IF GAP IS 3/8 IN. OR MORE.
- (5) MAKE SURE COUPLING IS LATCHED AND THAT LATCH WILL NOT OPEN.
- (6) PRIOR TO USE, ALWAYS CONNECT SAFETY CHAINS OF ADEQUATE STRENGTH FOR LOAD(S) BEING TOWED.
- (7) DO NOT BIND-UP (JACKKNIFE) ANY APPLICATION AS STRESSES CAN CAUSE DAMAGE TO THE COUPLING, DRAWBAR EYE, OTHER COMPONENTS OR ANY COMBINATION OF THEM. JACKKNIFING MAY RESULT IN FAILURE OF PRODUCTS OR COMPONENTS, RESULTING IN DETACHMENT OF THE TRAILER WHILE IN USE.

- (8) DO NOT APPLY LUBRICANTS TO THE COUPLING HOOK OR DRAWBAR EYE LOOP, AS THEY CAN COVER UP POSSIBLE DAMAGE AND ACCELERATE WEAR.
- (9) ALWAYS ABIDE BY ALL APPLICABLE STATE AND FEDERAL REGULATIONS GOVERNING SAFE AND PROPER TRANSPORTATION.
- (10) NEVER STRIKE ANY OF THESE COMPONENTS WITH A HAMMER OR ANY OTHER DEVICE.
- (11) ALWAYS VERIFY PROPER OPERATION OF LATCHING SYSTEM AND COUPLING COMPONENTS PRIOR TO DRIVE OFF.
- (12) NEVER USE A COUPLING THAT YOU DO NOT FULLY UNDERSTAND HOW TO PROPERLY OPERATE AND VERIFY SECURE LATCHING OF.
- (13) NEVER REPLACE ANY PART IN ANY OF PREMIER'S ASSEMBLIES WITH NON-PREMIER COMPONENTS. DOING SO WILL VOID ALL WARRANTY AND POTENTIALLY COMPROMISE THE UNIT'S INTEGRITY, WHICH COULD RESULT IN PROPERTY DAMAGE, SERIOUS INJURY, OR DEATH.



Table of Contents

Description Page 1	age
Attention all Distributors,	
<u>OEMs & Customers</u> : Important	
Warning Instructions	2
Selecting Equipment	4-8
How to Select	
Coupling to Drawbar Eye Cross	
Reference Chart	6
Wear Gage to Coupling Cross Reference Chart	7
Wear Gage to Drawbar Eye Cross	7
Reference Chart Premalloy Description	
Saf-Tite Description	
Extended Life "EL" Description	
Saf-T-Latch Description	
Couplings Slack Reducing System	
16	
24	
100	
100-3	
1400 <u>NEW PRODUCT</u>	
1400H <u>NEW PRODUCT</u>	
130	
135NT	
140	
150	. 33
160	. 34
160HD	. 35
235NT	. 36
240	. 37
240K	. 38
270	. 20
335NTEL <u>NEW PRODUCT</u>	39
370	. 21
370B	
470	. 23
470H	
480	
570	
580	
580J	
690L	
820ELA <u>NEW PRODUCT</u>	
880 890CL / 890CR	
2200 / 2200L	
2200/2200L	
2300	
2400	
2400H	
2880	

Description	Page
Drawbar Eyes Drawbar Eye to Wear Gage Cros Reference Chart	s
2	
3	
4	
5	
6	
6A	
8	
20	
21	
22	
23	
108	
110	
123	
127 / 127F	
200	
200L	
205	
207	
238DB	55
245DB	55
245DB-3	55
300	54
300HD	54
304	52
305	50
307	56
307BK	61
309	52
405	57
407SE	56
Adjustable Drawbar Eye	46
Induction Hardening	
Front End Housings	58-61
340S / 340SA	
435 / 435A	
536	
546	
556	60
640S / 640SA	59
956BK	61
Hinge Assemblies	62.65
320 / 320A	
330 / 330A	
430 / 430A	
440 / 440A	
450 / 450A	
455 / 455A	
930A	

Description	Page
Dolly Jacks Jack Selection Guide	
600	68
700	69
Swivel Mounts	69
800	
Casters	70
Replacement Parts Illust	71
Accessories	72-78
150 Coupling Balls	77
165 Receiver	
166 Receiver	
500 Slack Adjuster	
Air Chambers	
Air Chamber Brackets	
Bolt Kits	
Couplers	
Drawbar Guides	
Parts Kits & Repair Kits	
Safety Chain Hangers	
Thimbles	
Tow Hooks	
Wear Gages	73
Glossary of Terms	79-80
Notes Section	81-82
Warranty	83



Selecting The Right Equipment


Whatever your application, selecting the proper equipment for the job is very important. Proper selection along with regular inspection and maintenance will help keep operating costs minimal while providing long life to each component. Below are general guidelines for selecting Premier Couplings and Drawbar Eyes. If you feel that your application is unique, please give Premier a call so that we may help you through the selection process.


Follow these four steps to ensure proper selection of Premier Couplings and Drawbar Eyes.



Step 1: Determine "Gross Trailer(s) Weight"

"Gross Trailer(s) Weight" is usually determined by the Gross Vehicle Weight Rating (GVWR). This information is attached to the trailer by the trailer manufacturer.





For "Double Trailer" configurations, only the rear trailer is considered when selecting your Premier Coupling or Drawbar Eye. In this example, a Coupling and Drawbar Eye with a "Gross Trailer Weight" rating of 40,000 lbs. [18,143 kg] would be the minimum rating acceptable for normal, over-the-road applications (see Tongue Weight section below).



For "Triple Trailers", only the two most rearward trailers are considered in selecting your Premier Coupling or Drawbar Eye. In this example, a Coupling and Drawbar Eye with a "Gross Trailer Weight" rating of 80,000 lbs. (36,287 kg) would be the minimum acceptable for normal, over-theroad applications (see Tongue Weight section below).

Step 2: Determine "Tongue Weight Capacity"



"Tongue Weight Capacity" is the maximum expected weight at the drawbar eye. If a hinged drawbar is used, the maximum weight will be approximately 1/2 the overall drawbar weight. If a non-hinged drawbar is used and the actual tongue weight is not known, you can approximate the weight by multiplying the GVWR of the towed trailer by 15%. However, each application is unique and the best practice is to weigh the tongue when the trailer is loaded to its GVWR.

Step 3: Considering Operating Conditions and Environments

Environments such as rough uneven roads or off-road use can dramatically increase shock loads to both drawbar eyes and couplings. In general, increasing the "Gross Trailer Weight" (Step 1:) and "Tongue Weight Capacity" (Step 2:) by a minimum of 25% will be sufficient for many applications. Even if an application is used off-road occasionally, the minimum increase necessary for Gross Trailer and Tongue Weight is 25%. Certain types of equipment and/or operating practices can also dramatically increase loads through equipment binding and/or improper loading practices. Of special concern is high tongue weight. However, each application is unique and every environment different, therefore your application may require more than 25%.

Once both "Gross Trailers(s) Weight" (Step 1:) and "Tongue Weight Capacity" (Step 2:) have been determined, evaluate your operating conditions and apply an appropriate margin of safety.


Step 4: Browse Premier Product Catalog

Browse the Premier Product Catalog and refer to the "Specifications" section of each product. Be sure to review the "Understanding Premier Load Specifications" section and "Coupling to Drawbar Eye Cross-Reference" sheet on the next couple pages.



Understanding Premier Load Specifications

Each Premier product undergoes extensive design and testing prior to being introduced. We use the latest in Computer Aided Design and Analysis Software as well as physical destructive tests. Premier's published load specifications are the maximum load a given product or part will withstand without failure. Premier's testing procedures closely follow the Society of Automotive Engineers (SAE) guidelines of Recommended Practice for testing Couplings and Drawbar Eyes (SAE J847 & J849).



Importance of Inspection and Maintenance

Safety is our #1 Priority: Through high quality designs and unsurpassed quality control procedures, Premier assures our customers that our focus on safety continues to be our #1 priority.

Scheduled Inspection & Maintenance: Regularly scheduled inspection and maintenance are essential for maintaining safe and efficient operations whether you are using Couplings, Drawbar Eyes, Jacks, Hinge Assemblies, or any other Premier product. Inspection and maintenance are necessary for proper function and will also keep repair costs to a minimum.

Technical Literature: Premier provides important literature to assist you with our products. We package and attach *Installation, Inspection, Operation & Maintenance Guides, or Service Guides*, to each of our major products. This literature is also available to view and/or print from our website at <u>www.premier-mfg.com</u>. These supply you with important information and help guide you through installation, inspection, operation, routine maintenance and part replacement.

Wear Gages: In accordance with the Federal Motor Carrier Safety Regulations, we created Wear Gages to assist you in determining the wear limits of Premier couplings and drawbar eyes. See details on catalog pages 7 & 73.

Additional Product Resources at Your Fingertips

Customer Service: We are always here to support you. Do you need additional information or assistance? Your phone calls are greeted by our courteous receptionist, during business hours. We have exceptional, personable Customer Service Reps for you to rely on. If you have product questions or want to place an order, you can speak directly with one of our experienced and knowledgeable Customer Service Representatives.

Sales Representatives: Would you like on site training or assistance? Contact one of our veteran Premier Sales Reps for more information about product training for your staff. Or be sure to visit with them at a Trade Show (see website for schedule).

www.premier-mfg.com: Our website is an informative resource at your fingertips. In addition to our Installation and Service Guides, you will find our Sales Representatives, distributor locations, online catalog pages, product specifications, how to select product, trade show schedule, and links to trucking resources.



Selecting The Right Equipment

					C	oup	olin	g -	to	- D	ra	wb	ar	Eye	э, (Cro	oss	Re	efe	rer	nce	Cł	nar	't							
																									T						2
			1	1		I	I		1				I		DRA	NBAR	EYE	S				I			I	I			I		
		2*	3	4	5	6/6A	8	11	20	21	22	23	107	108	110	123	127	200	200L	205	207	238DB	245DB	245DB-3	300/300HD	304	305	307	309	405	407SE
	16	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	24*	•																													
	100†			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	100-3†			•	•	•	•	•	•	•	٠	•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	100-4†			•	•	•	•	•	•	•	٠	•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	100-4H†			•	•	•	•	•	•	•	•	•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	130	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			•	•	•
	135NT		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•		•		_
	140	•	•						•																						_
	150			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	160	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	235NT			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•		•		_
	240		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	240K			•	•	•	•	•	•	•	•	•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	270			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	335NTEL									-			-	•			-		-		-			•	•	•		-	•		_
S	360			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
TING	370			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
COUPLINGS	370B			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
3	470			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	470H			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	480			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	<u> </u>	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
				•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	580J 690L			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	780			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	790																					•		•	•	•	•	•	•		
	820ELA			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	880																					•		•	•	•	•	•	•		
	890/890C			•	•	•	•	•	•	•	•	•			•	•		•	•	•		•	•	•	•	•			•		
	1400			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	1400H	V.		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	2200			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	2300			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	2400			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	2400H			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	2800																					•		•	•	•	•	•	•		
					-							-			_																

† Saf-Tite Product

* Industrial Application

CAUTION: Verify that both the coupling's and drawbar eye's rated capacities meet your application(s) requirements.

Selecting The Right Equipment

Measure Wear for Safety Regulation Limits

To determine wear limits, Premier created **Wear Gages** that help judge the useful life of couplings and drawbar eyes (details on page 73). In accordance with Premier and the Federal Motor Carrier Safety Regulations, these were designed to identify wear at the critical percentages of 18% and 20%, by measuring the cross-section of coupling hooks (horn) and drawbar eye loops. 18% wear indicates that the product should be replaced as soon as possible. At 20% wear, the product is no longer in usable condition and must be taken out of service immediately and replaced.



The latch gage bar (14026) measures the gap space between the top of the coupling hook and the closed latch. If our 3/8" latch gage bar can pass between this region, then the latch components should be considered worn past safe limits and replaced. Please note that these wear gage specifications are in accordance with Premier Mfg. Co. and the Federal Motor Carrier Safety Regulations (refer to other manufacturer's specifications for wear limits on their products).

Our **Wear Gages** were designed to identify wear by measuring the cross-section of drawbar eye loops and coupling pintle hooks.

18% wear indicates that the product should be replaced as soon as possible. At 20% wear, the product is no longer in usable condition and must be taken out of service immediately and replaced (see pg 73).

Coupling	Wear Gage #
16	n/a
24	n/a
100	14014, 14026*
100-3	14014, 14026*
100-4/100-4H	14014, 14026*
1400/1400H	14014, 14026*
130	14005, 14026*
135NT	14008, 14026*
140	14026*, 14032, 14035
150	14026*
160	14026*, 14035
235NT	14011, 14026*

Coupling - to - Wear Gage, Cross Reference Chart

Coupling	Wear Gage #
240	14008, 14026*
240K	14011, 14026*
270	14011, 14026*
335NTEL	14020, 14026*
360	14011,14026*
370	14011, 14026*
370B	14011, 14026*
470	14011, 14026*
470H	14011, 14026*
480	14014, 14026*
570	14011, 14026*
580	14008, 14026*

Coupling	Wear Gage #
580J	14011, 14014, 14026*
690L	14014, 14026*
780	14011, 14014, 14026*
790	14026*
820	14014, 14026
880	14020, 14026*
890CL/890CR	14014, 14026*
2200	14014, 14026*
2300	14014, 14026*
2400	14014, 14026*
2400H	14014, 14026*
2880	14038, 14026*

*14026 is the Latch Gage Bar to measure the gap space between latch & hook.

Drawbar Eye	Wear Gage #
2	n/a
3	14002
4	14005
5	14005 & 14008
6	14032
6A	14032
8	14005
11	14002
20	14005
21	14005
22	14005
23	14005

Drawbar Eye - to - Wear Gage, Cross Reference Chart

Drawbar Eye	Wear Gage #
107	14005 & 14032
108	14005 & 14032
110	14005 & 14032
123	14005
127/127F	14005 & 14032
200	14005
200L	14005
205	14005 & 14032
207	14005





Premalloy - Premier's Exclusive Alloy

"The harder you work it, the harder it gets" best describes how Premalloy performs. Premalloy actually work-hardens at the contact surfaces during normal use, which results in longer service life. Premalloy is highly recommended for off-road and aggregate type applications due to its wearresistant characteristics. Many of Premier's couplings are made from this exclusive material.

As you are browsing the catalog, look for the Premalloy icon next to the product photos to determine which models are made of this material.

Saf-Tite - Strength and Value

"Raising the Bar in Strength & Value" If you need a maximum strength coupling at a value, this is the product for you. Saf-Tite couplings are unsurpassed in their Maximum Gross Trailer Weight capacities and they have easy to operate latch systems with polymer pivot points. The difference is evident when you compare the capacities of these high strength couplings against competing models. And to top it off, these quality couplings are available to you at a value when you compare costs.

Saf-Tite coupling models 100, 100-3, 100-4 and 100-4H can be found on pages 10-13.

Extended Life - Your Ally Against Corrosion

The "Extended Life" latch option (EL) is now available on our 2000 Series Couplings. This new design was a direct response for you to fight the war on corrosion. We engineered latch lubrication ports that deliver lubricant directly to the pivot points of our latch system. This direct-inject system provides for a rapid delivery of lubricant - right where it counts. The result is smooth, consistent latch performance over an extended period of time.

You can request the EL option with our 2200, 2300, 2400, 2400H and our New 2880 coupling "The Beast".

See page 15 for more details about the EL, and see page 19 for details on the 2880 coupling.

Saf-T-Latch - Lock In Safety and Security


The patented Saf-T-Latch has a small air cylinder inside the coupling body that is connected to the air chamber. When the chamber is pressurized by releasing the emergency brake, the cylinder rod extends and contacts the pocket in the lower latch which rotates to the closed position in the event the latch is inadvertently left open.

*Closing and making sure the latch is closed correctly is always the responsibility of the person making the coupling connection and the driver's responsibility to verify that the equipment is correctly connected prior to moving the vehicle. In the event the coupling is not properly closed, the Saf-T-Latch acts as a safeguard to close the latch with the release of the air brakes.

1-800-255-5387



PREMIER-MFG.COM





Raising the Bar with Strength & Value





8



SLACK REDUCING COUPLINGS

PREMIER'S SLACK REDUCING SYSTEM WAS SPECIFICALLY DESIGNED TO IMPROVE DRIVABILITY AND REDUCE WEAR.

This is accomplished by applying a clamping force with our shoe against the drawbar eye. The shoe thereby keeps the drawbar eye snug against the pintle (horn) at the coupling to drawbar eye connection. This drastically reduces the slamming, back and forth movement of the drawbar eye loop on the coupling pintle (horn).

Drawbar Eye with slack <u>Note</u>: The drawbar eye and coupling are sliced in half for viewing purposes. The light gray represents the cut portions.

NO SLACK REDUCING SYSTEM

This image shows the internal components of the connection between the drawbar eye and the coupling without our slack reducing system. Note that there is slack that would allow the drawbar eye to move back & forth on the pintle (horn) when in use.


> Drawbar Eye slack reduced

WITH SLACK REDUCING SYSTEM

This image shows the slack reducing system in operation and the shoe in the clamped position. With the shoe engaged, the drawbar eye is now snug against the pintle (horn). This removes the slack between the two components, thereby taking out the freeplay movement and improving drivability.



100 Saf-Tite Slack Reducing Coupling



*Not included in 100PK Parts Kit, available as 279PK Parts Kit.

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly

- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

R

PREMIER-MFG.COM

- Lubricate all coupling components at a minimum of 90 day intervals


- Do not bind-up (Jackknife) any application as stresses can cause damage to products

or components, resulting in failure and detachment of the trailer while in use

*274

*274A

100-3 Saf-Tite Slack Reducing Coupling



- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use



	ORDERING INFORMATION
OPERATION WITH OR WITHOUT AIR SERVICE CHAMBER	 Description of the second se
85	Maximum Gross Trailer Weight: 110,000 lbs. (49,895 kg) Maximum Tongue Weight: 20,000 lbs. (9,072 kg)
The NEW 1400 replaces the discontinued 100-4 used in heavy duty applications. Using the latest technology, engineers reduced the weight while	Ultimate Latch Capacity: 60,000 lbs. (27,216 kg) Maximum Eye X-Section: 1 13/16 in. (46 mm) Minimum Eye Opening: 2 3/8 in. (60 mm)
increasing the surface hardness and raising the latch capacity to 60,000 lbs. STANDARD INST	Unit Weight: 31.6 lbs. (14.3 kg)
	AMBER)
	of mounting structure for standard installations as illustrated. T PART INFORMATION
2000PK Parts Kit Includes:44-62: Retaining Ring (2)2073A: Spring297: Locknut2073B: Bushing373B: Spacer* 266: Spring38B: Pin* 271: Thimble2071: Bolt* 274: Bolt2072: Latch* 274A: Locknut2072A: Spring* 279: Shoe2072B: Bushing* * 2075: Lever2073B: Bushing* * 2075: Lever2073C: Latch Lock* * 44-62: Retaining Ring (2)*Not included in 2000PK Parts Kit, available as a separate kit (2075K).* * 373B: Spacer	2071 2072 2072 2072 2072 2072 2073 2074 2075
IMPORTANT GUIDELINES THAT APPLY T Do not weld on any coupling assembly Always use Grade-8 fasteners properly torqued Do not apply lubricants to the counting book	TO ALL PREMIER SLACK REDUCING COUPLINGS - Lubricate all coupling components at a minimum of 90 day intervals - Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and datachment of the trailer while in use


- e-8 fasteners properly torq - Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387



PREMIER-MFG.COM

or components, resulting in failure and detachment of the trailer while in use



- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

- Do not bind-up (Jackknife) any application as stresses can cause damage to products

- or components, resulting in failure and detachment of the trailer while in use
- 1-800-255-5387



2200 / 2200L Slack Reducing Coupling



The model 2200, like our ever popular 270 coupling, features the most popular mounting bolt pattern in the industry. All our 2000 series couplings feature exceptional latch strength, easy operation and low maintenance. All 2000 series couplings can be operated with or without an air service chamber.


ORDERING INFORMATION

- Coupling Only:
- 2200 & 271 Thimble
 - 2200L: 2200 with 2075K Low Profile Lever Kit installed
- Standard Installation Kit:
- 2200A: 2200 Coupling, 501 Bolt Kit, 281 Air Chamber, 267 Air Chamber Adapter Bracket, 271 Thimble
- Optional Accessories:
 - Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
 - Air Chamber Brackets (pg 74): 267H (3/4 in. / 19 mm), 267F (4 5/8 in. / 117 mm)
 - Low Profile Lever Kit 2075K: Designed for low clearance installations (enables one-handed latch operation from the left side)
 - Thimbles (pg 74): 271B (4 3/8 in. / 111 mm) 271C (5 1/2 in. / 140 mm)
 - Drawbar Guides 438 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 501 (pg 75): Bolts (2) 2 1/2 in. (2) 2 3/4 in., Locknuts (4)

SPECIFICATIONS


100,000 lbs.	(45,359 kg)
20,000 lbs.	(9,072 kg)
60,000 lbs.	(27,216 kg)
1 13/16 in.	(46 mm)
2 3/8 in.	(60 mm)
29 lbs.	(13.2 kg)
	20,000 lbs. 60,000 lbs. 1 13/16 in. 2 3/8 in.

STANDARD INSTALLATION DRAWING



Pushrod length is 3 5/8 in. (92 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use


1-800-255-5387

 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

- Lubricate all coupling components at a minimum of 90 day intervals

PREMIER-MFG.COM

2200EL / 2200ELL Slack Reducing Coupling



- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use
- 1-800-255-5387





Popular with tanker fleet customers, the 2300 can be used throughout the industry. Like our 2200, the 2300 is also made from Premalloy for long life. As with all 2000 series couplings, the 2300 offers unsurpassed latch strength and can be operated with or without an air service chamber.

ORDERING INFORMATION

- Coupling Only:
- 2300 & 271 Thimble
- 2300EL: 2300 with Extended Life latch direct-inject latch lubrication ports
- Standard Installation Kit: - 2300A: 2300 Coupling, 502 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble
 - 2300ELA: 2300EL Coupling, 502 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble
- **Optional Accessories:**


Ma

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
- Air Chamber Brackets (pg 74): 467H (3/4 in. / 19 mm), 467F (5 1/2 in. / 140 mm)
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm), 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 378 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 502 (pg 75): Bolts (4) 2 1/2 in. (2) 2 3/4 in., Locknuts (6)

SPECIFICATIONS

ximum Gross Trailer Weight:	100,000 lbs.	(45,359 kg)
Maximum Tongue Weight:	20,000 lbs.	(9,072 kg)
Ultimate Latch Capacity:	60,000 lbs.	(27,216 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	30.3 lbs.	(13.7 kg)

STANDARD INSTALLATION DRAWING



Pushrod length is 3 5/8 in. (92 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION

2000PK Parts Kit Includes:

44-62:	Retaining Rin	ng (2)	2073A:	Spring
297:	Locknut		2073B:	
373B:	Spacer		*266:	Spring
388:	Pin		*271:	Thimble
2071:			*274:	
2072:				Locknut
2072A:			*279:	Shoe
	Bushing			
2073:	Latch Lock			

*Not included in 2000PK Parts Kit, available as 279PK Parts Kit.

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387



2071

С

2073B

0

44-62

2072B

2073

297

M

2073A

- Lubricate all coupling components at a minimum of 90 day intervals

2072A

2072

373B 🜔

- Do not bind-up (Jackknife) any application as stresses can cause damage to products

or components, resulting in failure and detachment of the trailer while in use

0

44-67

******* *266

274

*274A

ORDERING INFORMATION



When installation and mounting is limited by bolt hole pattern, the 2400 may be the answer. Although one of the bottom three mounting holes must be used, you choose which one. This allows for maximum compatibility with existing mounting patterns. Popular with Pup and Dumps and Tanker applications. All 2000 series couplings can be operated with or without an air service chamber.

Coupling Only:

- 2400 & 271 Thimble
- 2400EL: 2400 with Extended Life latch direct-inject latch lubrication ports

Standard Installation Kit:


- 2400A: 2400 Coupling, 508 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble
- 2400ELA: 2400EL Coupling, 508 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble

Optional Accessories:

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
- Air Chamber Brackets (pg 74): 467H (3/4 in. / 19 mm), 467F (5 1/2 in. / 140 mm)
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm), 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 438 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 508 (pg 75): Bolts (6) 2 1/2 in. (2) 2 3/4 in., Locknuts (8)

SPECIFICATIONS

Maximum Gross Trailer Weight:	100,000 lbs.	(45,359 kg)
Maximum Tongue Weight:	20,000 lbs.	(9,072 kg)
Ultimate Latch Capacity:	60,000 lbs.	(27,216 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	34.3 lbs.	(15.6 kg)



REPLACEMENT PART INFORMATION

2000PK Parts Kit Includes:

	Retaining Ri Locknut	ng (2)	2073A: 2073B:	
	Spacer			Spring
388:			*271:	Thimble
2071:	Bolt		*274:	Bolt
2072:	Latch		*274A:	Locknut
2072A:			*279:	Shoe
	Bushing			
2073:	Latch Lock			

*Not included in 2000PK Parts Kit, available as 279PK Parts Kit.

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use
- Lubricate all coupling components at a minimum of 90 day intervals
 Do not bind-up (Jackknife) any application as stresses can cause damage to products

297

M

388

2073A

2072A

0 2073B

O

44-62

271

*266

*274

*279

*274A

2072

373B

0

- or components, resulting in failure and detachment of the trailer while in use
- 1-800-255-5387



2071

2072B

2073

ORDERING INFORMATION Coupling Only: - 2400H & 271 Thimble - 2400HEL: 2400H w/Extended Life latch direct-inject latch lubrication ports Standard Installation Kit: - 2400HA: 2400H Coupling, 508 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble - 2400HELA: 2400HEL Coupling, 508 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble Optional Accessories: - Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber - Air Chamber Brackets (pg 74): 467H (3/4 in. / 19 mm), 467F (5 1/2 in. / 140 mm) - Thimbles (pg 74): 271B (4 3/8 in. / 111 mm), 271C (5 1/2 in. / 140 mm) - Drawbar Guides 438 (pg 73): Helps guide drawbar eye into coupling - Wear Gage 14014 (pg 73): To determine hook wear limits PREMIER - Latch Gage 14026 (pg73): To determine latch gap limit - Bolt Kit 508 (page 75): Bolts (6) 2 1/2 in. (2) 2 3/4 in., Locknuts (8) **SPECIFICATIONS OPERATION WITH OR** 100,000 lbs. Maximum Gross Trailer Weight: (45,359 kg) WITHOUT AIR SERVICE Maximum Tongue Weight: 20,000 lbs. (9,072 kg) CHAMBER 60 000 lbs (27,216 kg) Ultimate Latch Capacity: Maximum Eye X-Section: 1 13/16 in. (46 mm) Similar to our 2400, but with a different mounting pattern. Minimum Eye Opening: All 2000 series couplings can be operated with or without 23/8 in. (60 mm) Unit Weight: 37.3 lbs. (16.9 kg) an air service chamber. STANDARD INSTALLATION DRAWING #281 AIR CHAMBER 467 AIR CHAMBER BRACKET 15/16 Ø11/2 (X-MEMBER DRILL) \oplus \oplus #467W WASHER 4 3/16 5/16 PREMIER \oplus Œ Ø 178 /14 \oplus 2400 H #271 THIMBLE 2 3/8 47 2 3/4 MOUNTING SURFACE 8 X Ø25/32 ON VEHICLE (X-MEMBER) 3/4 -- 21/8 -Pushrod length is 3 5/8 in. (92 mm) plus thickness of mounting structure for standard installations as illustrated. **REPLACEMENT PART INFORMATION** 2000PK Parts Kit Includes: 44-62: Retaining Ring (2) 2073A: Spring 2071 297: Locknut 2073B: Bushing 297 *271 373B: Spacer *266: Spring 2072 388: Pin *271: Thimble 2072B 2072A ******* *274: Bolt 2071: Bolt *266 2072: Latch *274A: Locknut M C 2072A: Spring *279: Shoe 2073B 2073A 373B 🔘 *279 2072B: Bushing 0 0 2073: Latch Lock *274 388 *2744 44-62 2073 *Not included in 2000PK Parts Kit, available as 279PK Parts Kit. **IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS** - Do not weld on any coupling assembly - Lubricate all coupling components at a minimum of 90 day intervals - Always use Grade-8 fasteners properly torqued - Do not bind-up (Jackknife) any application as stresses can cause damage to products - Do not apply lubricants to the coupling hook or components, resulting in failure and detachment of the trailer while in use

- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387



PREMIER-MFG.COM



This monster-of-a-coupling has a sleek design but was specifically engineered to tame tropical applications with GTW capacities of up to 85 tons. Made with our work-hardening Premalloy, for unsurpassed wear resistance. Easy to operate and you can get it with our new EL option.

ORDERING INFORMATION

Coupling Only:

- 2880 & 271 Thimble
- 2880EL: 2880 with Extended Life latch direct-inject latch lubrication ports

Standard Installation Kit:

- 2880A: 2880 Coupling, 511 Bolt Kit, 282 Air Chamber, 767 Air Chamber Adapter Bracket, 271 Thimble
- 2880ELA: 2880EL Coupling, 511 Bolt Kit, 282 Air Chamber, 767 Air Chamber Adapter Bracket, 271 Thimble

Optional Accessories:


- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm), 271C (5 1/2 in. / 140 mm)
- Wear Gage 14038 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 511 (pg 75): Bolt Kit 511 uses coarse threaded L9 Grade bolts. Bolts (6) 3 1/2 in., Locknuts (6)*

* Must use Bolt Kit 511 for Max Gross Trailer Weight of up to 170,000 lbs.


SPECIFICATIONS

Maximum Gross Trailer Weight:	170,000 lbs.*	(77,111 kg)
Maximum Tongue Weight:	30,000 lbs.	(13,608 kg)
Ultimate Latch Capacity:	60,000 lbs.	(27,216 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	3 in.	(76 mm)
Unit Weight:	42.1 lbs.	(19.1 kg)

STANDARD INSTALLATION DRAWING



REPLACEMENT PART INFORMATION



*Not included in 2000PK Parts Kit, available for sale individually.


IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use
- Lubricate all coupling components at a minimum of 90 day intervals
- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387



PREMIER-MFG.COM



Coupling Only: - 270 & 271 Thimble

Standard Installation Kit:

- 270A: 270 Coupling, 501 Bolt Kit, 281 Air Chamber, 267 Air Chamber Adapter Bracket, 271 Thimble


Optional Accessories:

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
- Air Chamber Brackets (pg 74): 267H (3/4 in. / 19 mm), 267F (4 5/8 in. / 117 mm)
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm) 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 378M (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 501 (pg 75): Bolts (2) 2 1/2 in. (2) 2 3/4 in., Locknuts (4)

SPECIFICATIONS

Naximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Ultimate Latch Capacity:	12,000 lbs.	(5,443 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	26.3 lbs.	(11.9 kg)

STANDARD INSTALLATION DRAWING



Pushrod length should be 3 5/8 in. (92 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION

270PK Parts Kit Includes:

Like our 2200, our 270 also offers the most popular bolt mounting pattern in the industry. Low profile, wear resistant Premalloy and easy quick latching are features that have made the 270 standard

This coupling must be used with an air service chamber.

with fleets around the world.

272:	Latch	*266:	Spring
273:	Pawl	*271:	Thimble
273A:	Spring	*274:	
273C:	Set Screw	*274A:	Locknut
274:	Bolt	*279:	Shoe
274A:	Locknut		
275:	Pin		
275-50:	Retaining Ring (2)		

275-50 O *270 275-50 274 *274 274A *274A

- Do not bind-up (Jackknife) any application as stresses can cause damage to products

or components, resulting in failure and detachment of the trailer while in use

*Not included in 270PK Parts Kit, available as 279PK Parts Kit

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387



PREMIER-MFG.COM

- Lubricate all coupling components at a minimum of 90 day intervals



Used frequently in dump and pup applications, our popular 370 offers users a low profile, high latch strength and our Premalloy body for maximum wear.

This coupling must be used with an air service chamber.

ORDERING INFORMATION

Coupling Only:

- 370 & 271 Thimble

Standard Installation Kit: - 370A: 370 Coupling, 502 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble


Optional Accessories:

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
- Air Chamber Brackets (pg 74): 467H (3/4 in. / 19 mm), 467F (5 1/2 in. / 140 mm)
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm) 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 378 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 502 (pg 75): Bolts (4) 2 1/2 in. (2) 2 3/4 in., Locknuts (6)

SPECIFICATIONS

90,000 lbs.	(40,823 kg)
18,000 lbs.	(8,165 kg)
20,000 lbs.	(9,072 kg)
1 13/16 in.	(46 mm)
2 3/8 in.	(60 mm)
30 lbs.	(13.6 kg)
	18,000 lbs. 20,000 lbs. 1 13/16 in. 2 3/8 in.

STANDARD INSTALLATION DRAWING



Pushrod length is 4 in. (102 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use
- Lubricate all coupling components at a minimum of 90 day intervals
 Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use
- 1-800-255-5387



PREMIER-MFG.COM



This coupling is designed for installations where rear clearance is a problem. Similar to our popular 370, the 370B allows for a bottom mount air can (see illustration below). This coupling must be used with an air service chamber.

ORDERING INFORMATION

Coupling Only:

- 370B & 271 Thimble


Standard Installation Kit:

- 370BC: 370B Coupling, 503 Bolt Kit, 281C Air Chamber, 271 Thimble
- Optional Accessories:
 - Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281C Air Chamber
 - Thimbles (pg 74): 271B (4 3/8 in. / 111 mm) 271C (5 1/2 in. / 140 mm)
 - Drawbar Guides 378 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 503 (pg 75): Bolts (6) 2 1/2 in., Locknuts (6)

SPECIFICATIONS

Maximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Ultimate Latch Capacity:	20,000 lbs.	(9,072 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	31 lbs.	(14.0 kg)

STANDARD INSTALLATION DRAWING



Pushrod length is 2 3/8 in, (60 mm). Not for use with rear mount air can.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

Lubricate all coupling components at a minimum of 90 day intervals
Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

ORDERING INFORMATION

Coupling Only:

- 470 & 271 Thimble

Standard Installation Kit: - 470A: 470 Coupling, 508 Bolt Kit, 281 Air Chamber, 467 Air Chamber Adapter Bracket, 271 Thimble


Optional Accessories:

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber
- Air Chamber Brackets (pg 74): 467H (3/4 in. / 19 mm), 467F (5 1/2 in. / 140 mm)
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm) 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 438 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 508 (pg 75): Bolts (6) 2 1/2 in. (2) 2 3/4 in., Locknuts (8)

SPECIFICATIONS


Maximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Ultimate Latch Capacity:	12,000 lbs.	(5,443 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	32.5 lbs.	(14.7 kg)

STANDARD INSTALLATION DRAWING



Pushrod length is 3 in. (76 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

Often used in the agricultural industry as well as tankers the 470 offers a similar latching system as our 270 but with a different

This coupling must be used with an air service chamber.

mounting pattern.

- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use

- Lubricate all coupling components at a minimum of 90 day intervals

1-800-255-5387



PREMIER-MFG.COM



Very similar to our 470, the 470H simply offers a different mounting pattern.

This coupling must be used with an air service chamber.

ORDERING INFORMATION

Product Discontinued No Longer Available

Alternate Option:

Our 2400H is an alternate option, which offers the same mounting pattern as our 470H. See page 18 for additional specifications.


470PK Parts Kit available for purchase

SPECIFICATIONS

Maximum Gross Trailer Weight:90,000 lbs.Maximum Tongue Weight:18,000 lbs.Ultimate Latch Capacity:12,000 lbs.Maximum Eye X-Section:1 13/16 in.Minimum Eye Opening:2 3/8 in.Unit Weight:32.6 lbs.

(40,823 kg) (8,165 kg) (5,443 kg) (46 mm) (60 mm) (14.8 kg)

STANDARD INSTALLATION DRAWING



Pushrod length is 3 in. (76 mm) plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

Do not bind-up (Jackknife) any application as stresses can cause damage to products
or components, resulting in failure and detachment of the trailer while in use

- Lubricate all coupling components at a minimum of 90 day intervals

PREMIER-MFG.COM

ORDERING INFORMATION

Coupling Only:

- 570 & 271 Thimble

Standard Installation Kit:

- 570A: 570 Coupling, 504 Bolt Kit, 281C Air Chamber, 271 Thimble


Optional Accessories:

- Air Chamber 282 Type-30 (pg 74): Provides a larger diaphragm for greater shoe force compared to 281C Air Chamber
- Thimbles (pg 74): 271B (4 3/8 in. / 111 mm), 271C (5 1/2 in. / 140 mm)
- Drawbar Guides 378 (pg 73): Helps guide drawbar eye into coupling
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit
- Bolt Kit 504 (pg 75): Bolts (6) 2 in., Locknuts (6)

SPECIFICATIONS

Maximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Ultimate Latch Capacity:	20,000 lbs.	(9,072 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	32.8 lbs.	(14.9 kg)

STANDARD INSTALLATION DRAWING



Pushrod length is 2 3/8 in. (60 mm).

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use

When vertical clearance is at a premium, the 570 and 770 may be your solution. Our 570 offers a bottom mount air chamber, low profile and strong latching system. An oil cup is provided to quickly

This coupling must be used with an air service chamber.

and easily lubricate latch.

 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

- Lubricate all coupling components at a minimum of 90 day intervals





Featuring our new **SAF-TLATCH** the 820ELA coupling assembly offers an exceptionally safe, strong, easy to use latch mechanism, Extended Life (EL) lubrication points, and the most popular bolt hole pattern in the industry. The latch mechanism includes a small auxiliary air cylinder that is connected to our 281 or 282 Air Chamber. This assists in ensuring the latching mechanism is closed while the vehicle is in motion.

This coupling must be used with an air service chamber.

ORDERING INFORMATION

Coupling Only:

- 820EL Coupling is not sold individually, must be ordered as a kit

Standard Installation Kit:

- **820ELA**: 820EL Coupling, 834 Air Line, 835 Reducer Fitting, 836 Fitting, 509 Bolt Kit, 281 Air Chamber, 267 Air Chamber Adapter Bracket, 271 Thimble

- **820ELA-Custom:** 820EL Coupling, 834 Air Line, 835 Reducer Fitting, 836 Fitting, 509 Bolt Kit, 281-Custom (specify length at time of order), 267 Air Chamber Adapter Bracket, 271 Thimble

- 820ELR: 820EL Coupling, 834 Air Line, 835 Reducer Fitting, 836 Fitting, 509 Bolt Kit, 281L Air Chamber, 271 Thimble

Optional Accessories:


-Air Chamber 282 Type-30: Provides a larger diaphragm for greater shoe force compared to 281 Air Chamber.

- -Wear Gage 14014 (2 1/8 in.): To determine hook wear limits.
- -Latch Gage 14026: To determine latch gap limit.

SPECIFICATIONS

Maximum Gross Trailer Weight:	100,000 lbs.	(45,359 kg)
Maximum Tongue Weight:	20,000 lbs.	(9,072 kg)
Ultimate Latch Capacity:	60,000 lbs.	(27,216 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	48.8 lbs.	(22.1 kg)

STANDARD INSTALLATION DRAWING



Pushrod Length: 4 5/16 in. (110 mm) plus thickness of mounting structure (x-member) for standard installations.

REPLACEMENT PART INFORMATION

820	DPK-EL Parts Kit li	ncludes:		834			821AL	275-50	44-62 44-62		279
273A:		*266:	Spring			821	D	O	0 0	271	
275-50:	Retaining Ring (2)	*271:	Thimble	/ 0	1		,	273A			
44-62:	Retaining Ring (4)	*274:	Bolt		020		821AR	12/3/			
821:	Pawl	*274A:	Locknut		830		Ρ		823	266	
821AL/AR:	Spring	*279:	Shoe	1 7			822	825		********	
823:	Pin	* *834:	Air Line	11	\square	RIL	JVL.	= 89	5C		
824:	Handle	* *835:	Reducer Fitting						0 0	274	
825:	Locking Pawl	* *836:	Fitting	16	-	999940	000	0 824	44-62 44-62		
837	Safety Pin & Cable	* * * 830	Auxiliary Air	T I		822AR ¹	822AL	275-50			274A
895C::	Set Screw		Cylinder	836	835		83	7		·	
*Not included in 82	OPK-EL Parts Kit, available	as 279PK Pa	rts Kit * * Available as	separate kit (834K)	***	Not included in			ailable individual	lly	

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply
- Clean & inspect coupling for damage & excessive wear prior to each and every use




- Lubricate all coupling components at a minimum of 90 day intervals

 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use



820ELA SLACK REDUCING COUPLING

The 820ELA is designed to close the latch when the 281 air chamber is pressurized. The small air cylinder inside the coupling body is connected to the 281 air chamber. When the 281 is pressurized, which happens when the emergency brake is released, the cylinder rod on the 830 air cylinder extends and contacts the pocket in the 822 lower latch until the 822 clears the 821.



<u>Note</u>: The drawbar eye and coupling are sliced in half for viewing purposes. The light gray represents the cut portions.

Torsion springs connected to the 821 and 825 rotate the parts to the closed position once the 822 is rotated to the closed position. This is intended to be an additional safety feature to help ensure the latch is closed. Closing and making sure the latch is closed correctly is always the responsibility of the person making the coupling connection and the drivers responsibility to verify that the equipment is correctly connected prior to moving the vehicle.





Product Discontinued No Longer Available

Alternate Option:


Our 2880 is an alternate option, which offers the same mounting pattern as our 880. See page 19 for additional specifications.

880RK Parts Kit available for purchase

SPECIFICATIONS

Maximum Gross Trailer Weight:	150,000 lbs.	(68,039 kg)
Maximum Tongue Weight:	30,000 lbs.	(13,608 kg)
Ultimate Latch Capacity:	30,000 lbs.	(13,608 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	З in.	(76 mm)
Unit Weight:	47.5 lbs.	(21.5 kg)

STANDARD INSTALLATION DRAWING



Pushrod length should be 5 3/8 in, [137 mm] plus thickness of mounting structure for standard installations as illustrated.

REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SLACK REDUCING COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Air service chamber must be Type-24 or Type-30 with 90-120 PSI air supply

Similar to our 780, Premier's 880 is the brute of couplings. With a maximum GTW of 150,000 lbs., this coupling was designed for the tough stuff. Featuring Premalloy alloy construction for maximum wear, the 880 will provide years of

service in even the most abusive environments. This coupling must be used with an air service chamber.

- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387



PREMIER-MFG.COM

- Lubricate all coupling components at a minimum of 90 day intervals

- Do not bind-up (Jackknife) any application as stresses can cause damage to products

or components, resulting in failure and detachment of the trailer while in use






NON-AIR COUPLINGS




16 & 24 Couplings



PREMIER-MFG.COM

130 & 140 Couplings





135NT Swivel Coupling

	ORDERING INFORMATION
	Coupling: - 135NT <u>Optional Accessories:</u> - Wear Gage 14008 (pg 73): To determine hook wear limits - Latch Gage 14026 (pg 73): To determine latch gap limit
REMIER.	SPECIFICATIONS
Utility companies, construction, agricultural and military operations will all benefit from Premier's 135NT and 235NT Swivel couplings. Swivel action eliminates torque between mated vehicles when traveling over rough, uneven terrain. NOT to be used with swivel-type drawbar eye.	Maximum Gross Trailer Weight: 30,000 lbs. (13,608 kg) Maximum Tongue Weight: 6,000 lbs. (2,722 kg) Ultimate Latch Capacity: 20,000 lbs. (9,072 kg) Maximum Eye X-Section: 1 11/16 in. (43 mm) Minimum Eye Opening: 2 1/16 in. (52 mm) Unit Weight: 25.8 lbs. (11.7 kg)
DRAW	/ING DETAIL
8 7/16 3 7/8 1 7/8 PREMIER 1 9/16 1 9/16 1 23/32 1 23/32	MOUNTING SURAFCE ON VEHICLE (X-MEMBER) (MAXIMUM 1" THICK)
the second se	PART INFORMATION
135PK Parts Kit Includes:131: Pin*135P: Mounting Plate [2]132: Latch*135SR: Retaining Ring132A: Spring*136: Locknut132B: Bushing*137NT: Polymer Washer [2]133: Latch Lock*138: Washer134: Pin*134B: Bushing135A: Spring*135A: Spring144-75: Retaining Ring [2]275-50: Retaining Ring [2]*Not included in parts kit, available individually.	144-75 0 132 132 132 132 134 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135A 135P
IMPORTANT GUIDELINES THA	T APPLY TO ALL PREMIER COUPLINGS
Do not weld on any coupling assembly	- Lubricate all coupling components at a minimum of 90 day intervals
 Always use Grade-8 fasteners properly torqued Do not apply lubricants to the coupling hook Clean & inspect coupling for damage & excessive wear prior to each and every use 	 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

NT.

1-800-255-5387

PREMIER-MFG.COM

150 Combination Coupling



165 /166 Receiver - Pg 78

One of Premier's most unique and versatile couplings is our popular model 150 Combination Coupling. Whether you need to pull a trailer with an eye or ball connection, the 150 can do the job. Our patented side-swing latch helps prevent tailgate damage and keeps the profile compact.

ORDERING INFORMATION

Coupling and Ball Combinations:


- 150: 150 coupling & 155 ball capacity MGTW: 10,000 lbs. (4,535 kg)
- 150-1: 150 coupling & 156 ball capacity MGTW: 10,000 lbs. (4,535 kg)

Optional Accessories:

- Bolt Kit 159: Four 1/2 in. (13 mm) O.D. x 2 in. (51 mm) long bolts, lock washers and nuts
- Adjustable mounts for receiver-type connections (pg 76):
 165 Receiver: 10,000 lbs. (4,535 kg) Max. gross trailer weight
 166 Receiver: 12,000 lbs. (5,443 kg) Max. gross trailer weight
- Replacement Balls (pg 77): 155 Ball: 2 in. (51 mm) Diameter 156 Ball: 2 5/16 in. (59 mm) Diameter
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight: Maximum Tonque Weight:	20,000 lbs. 2,500 lbs.	(9,072 kg) (1,134 kg)
Ultimate Latch Capacity: Maximum Eye X-Section:	5,000 lbs. 1 13/16 in. 2 3/8 in.	(2,268 kg) (46 mm) (60 mm)
Minimum Eye Opening: Unit Weight:	14.7 lbs.	(6.7 kg)




IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Clean & inspect coupling for damage & excessive wear prior to each and every use

- Lubricate all coupling components at a minimum of 90 day intervals
- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use



160 Coupling



The same unique latching as our model 150, the model 160 offers a compact profile for tight places. Ideal for dolly haul back and other light to medium duty applications.

ORDERING INFORMATION

Coupling:

- 160


Optional Accessories:

- Bolt Kit 159: Four 1/2 in. (13 mm) O.D. x 2 in. (51 mm) long bolts, lock washers and nuts
- Adjustable mounts for receiver-type connections (pg 76): 165 Receiver: 10,000 lbs. (4,535 kg) Max. gross trailer weight 166 Receiver: 12,000 lbs. (5,443 kg) Max. gross trailer weight - Wear Gage 14035 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight:	30,000 lbs.	(13,608 kg)
Maximum Tongue Weight:	4,500 lbs.	(2,041 kg)
Ultimate Latch Capacity:	5,000 lbs.	(2,268 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 in.	(51 mm)
Unit Weight:	14.4 lbs.	(6.5 kg)

DRAWING DETAIL



REPLACEMENT PART INFORMATION

150PK Parts Kit Includes:

- 151: Trigger 152: Latch 152B: Bushing 153A: Spring 153B: Roll Pin 154: Latch Pin 274: Bolt
- 274A: Locknut





IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly

- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

- Lubricate all coupling components at a minimum of 90 day intervals

- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use
 - PREMIER-MFG.COM

160HD Coupling



The model 160HD offers the same compact profile as the 160 with an additional 10,000 lbs. of gross trailer weight capacity and 2,000 lbs. of tongue weight capacity.

ORDERING INFORMATION

<u>Coupling:</u> - 160 HD


Optional Accessories:

- Wear Gage 14035 (pg 73): To determine hook wear limits - Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight:	40,000 lbs.	(18,144 kg)
Maximum Tongue Weight:	6,500 lbs.	(2,948 kg)
Ultimate Latch Capacity:	5,000 lbs.	(2,268 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 in.	(51 mm)
Unit Weight:	14.4 lbs.	(6.5 kg)

DRAWING DETAIL



REPLACEMENT PART INFORMATION

150P	K Part	s Kit Inc	ludes:

151:	Trigger
152:	Latch
152B:	Bushing
153A:	Spring
153B:	Roll Pin
154:	Latch Pin
274:	Bolt
274A:	Locknut

- Do not weld on any coupling assembly

- Always use Grade-8 fasteners properly torqued

- Do not apply lubricants to the coupling hook

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Lubricate all coupling components at a minimum of 90 day intervals
- Do not bind-up (Jackknife) any application as stresses can cause damage to products


154

- or components, resulting in failure and detachment of the trailer while in use
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

· 🥷


235NT Swivel Coupling



- Clean & inspect coupling for damage & excessive wear prior to each and every use

PREMIER-MFG.COM

240 Coupling



- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- · Clean & inspect coupling for damage & excessive wear prior to each and every use

Do not bind-up (Jackknife) any application as stresses can cause damage to products

- or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387

240K Coupling





The 240K is a direct result of customer requests for a King T-22 pintle hook replacement model. Utilizing customer input, this coupling was engineered with a time-tested latch system, which is used on many of our models. This strong, easy to operate, strike-resistant latch system is a proven performer within our product line. The pintle body is made of Premalloy, for extra toughness and wear resistance. This results in many years of service, which our customers have come to expect from this exclusive material.

Coupling: - 240K

- 240KL: 240K with 133KL Left Bar Latch Lock installed


Optional Accessories:

- Left Bar Latch Lock 133KL: Enables user to push back the 133 Latch Lock from the left side of the coupling, instead of from the top
- Wear Gage 14011 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight:	45,000 lbs.	(20,412 kg)
Maximum Tongue Weight:	6,000 lbs.	(2,722 kg)
Ultimate Latch Capacity:	20,000 lbs.	(9,072 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	17.1 lbs.	(7.8 kg)

DRAWING DETAIL



REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook

- Lubricate all coupling components at a minimum of 90 day intervals
- Do not bind-up (Jackknife) any application as stresses can cause damage to products

1-800-255-5387

or components, resulting in failure and detachment of the trailer while in use

Clean & inspect coupling for damage & excessive wear prior to each and every use



335NTEL Coupling



coupling needs, take Charge with the RHINO!

ORDERING INFORMATION

- Coupling:
- 335NTEL

Optional Accessories:

- Wear Gage 14020 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

110,000 lbs.

20,000 lbs.


65.000 lbs.

1 3/4 in.

63.5 lbs.

З in.

Maximum Gross Trailer Weight: Maximum Tongue Weight: Ultimate Latch Capacity: Maximum Eye X-Section: Minimum Eye Opening: Unit Weight: (49,895 kg) (9,072 kg) (29,484 kg) (44 mm) (76 mm) (28.8 kg)



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly

**334-81: Retaining Ring

- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387


* * * Available individually

- Lubricate all coupling components at a minimum of 90 day intervals

- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use



480 Coupling





PREMIER-MFG.COM

580 Coupling



A long time favorite of the logging industry, Premier's 580 coupling offers a low profile and a very popular mounting pattern. External oil cup enables easy lubrication of internal latch components.

ORDERING INFORMATION

Coupling:


- 580

Optional Accessories:


- Bolt Kit 507: Four 3/4 in. (19 mm) O.D. x 2 3/4 in. (70 mm) long bolts and locknuts
- Wear Gage 14008 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight:	70,000 lbs.	(31,751 kg)
Maximum Tongue Weight:	14,000 lbs.	(6,350 kg)
Ultimate Latch Capacity:	30,000 lbs.	(13,608 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 in.	(51 mm)
Unit Weight:	21.3 lbs.	(9.65 kg)



DRAWING DETAIL



REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook

Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

- Lubricate all coupling components at a minimum of 90 day intervals
- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use



580J Coupling



The same rugged features of our 580, our 580J offers a higher load rating and slightly different mounting pattern. Protected internal latch parts, easy lubrication and ease of operation are trademarks of all our 80 series couplings.

ORDERING INFORMATION

Coupling:


- 580J

- Optional Accessories:
 - Bolt Kit 503: Six 3/4 in. (19 mm) O.D. x 2 1/2 in. (64 mm) long bolts and locknuts
 - Wear Gage 14011 (pg 73): To determine hook wear limits
- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

Maximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Ultimate Latch Capacity:	30,000 lbs.	(13,608 kg)
Maximum Eye X-Section:	1 13/16 in.	(46 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	25.3 lbs.	(11.5 kg)

DRAWING DETAIL



REPLACEMENT PART INFORMATION

	*581: Handle Assembly
580RK Parts Kit Includes:	
266: Spring583: Pawl375A: Locknut584: Bolt387: Locknut585: Spring581A: Handle*581: Handle As581BB: Clip & Cable581C: Bushing582: Latch582A: Spring	ssembly
*Not included in parts kit, available individually.	387 266 353 35155

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly

- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

- Lubricate all coupling components at a minimum of 90 day intervals

- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use
- R


690L Drop-Pintle Coupling

ORDERING INFORMATION Coupling: Hook Only - 690L **Optional Accessories:** long bolts and locknuts 690L SPECIFICATIONS Premier's 690L coupling offers similar features to our model 590 but with a higher load capacity. The drop-pintle hook is made of Premier's exclusive Premalloy, for maximum wear resistance. **DRAWING DETAIL** 690L 61/2 21/4 -4 X Ø25/32 S 1 7/16 1 7/32 \oplus Ø 57/8 31/4 \oplus \oplus PREMIER 1 13/32 3 7/32 - 5/8 - 71/2 5 25/32 2 1/8 -913/32 7 29/32 **REPLACEMENT PART INFORMATION** *691L: Handle Assembly 690LRK Parts Kit Includes: 692: Hook 16DS: Drive Screw *693: Pawl 266: Spring ******** * * 294: Bolt 266 695: Spring 6910 * * 297: Locknut 387: Locknut 16DS 581EF: Clip & Cable *693 581EF 691: Handle

- Bolt Kit 507: Four - 3/4 in. (19 mm) O.D. x 2 3/4 in. (70 mm)

- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

Maximum Gross Trailer Weight:	90,000 lbs.	(40,823 kg)
Maximum Tongue Weight:	18,000 lbs.	(8,165 kg)
Upward Vertical Capacity:	40,000 lbs.	(18,144 kg)
Maximum Eye X-Section:	1 11/16 in.	(43 mm)
Minimum Eye Opening:	2 3/8 in.	(60 mm)
Unit Weight:	41.8 lbs.	(19 kg)



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly
- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook

- Do not bind-up (Jackknife) any application as stresses can cause damage to products

699

- Lubricate all coupling components at a minimum of 90 day intervals

- or components, resulting in failure and detachment of the trailer while in use
- Clean & inspect coupling for damage & excessive wear prior to each and every use

*Available individually * *Available for sale as 294K

1-800-255-5387

29

890CL / 890CR Drop-Pintle Coupling



Premier's 890C offers a mounting pattern for compatibility with existing x-members and can be converted to left or right-hand operation. The hook is made of Premier's exclusive Premalloy, for maximum wear resistance. <u>NOT to be used for A-Dolly applications.</u>

ORDERING INFORMATION

Coupling:

- 890CL / 890CR
- 890C: 890CL and 890CR sold together

Optional Accessories:

- Bolt Kit 507: Four 3/4 in. (19 mm) O.D. x 2 3/4 in. (70 mm) long bolts, and nuts
- Wear Gage 14014 (pg 73): To determine hook wear limits
- Latch Gage 14026 (pg 73): To determine latch gap limit

SPECIFICATIONS

(40,823 kg) (8,165 kg) (8,165 kg)


(46 mm)

(60 mm)

(28.2 kg)

Maximum Gross Trailer Weight:	90,000 lbs.
Maximum Tongue Weight:	18,000 lbs.
Upward Vertical Capacity:	18,000 lbs.
Maximum Eye X-Section:	1 13/16 in.
Minimum Eye Opening:	2 3/8 in.
Unit Weight:	62.2 lbs.

DRAWING DETAIL



REPLACEMENT PART INFORMATION



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER COUPLINGS

- Do not weld on any coupling assembly

- Always use Grade-8 fasteners properly torqued
- Do not apply lubricants to the coupling hook
- Clean & inspect coupling for damage & excessive wear prior to each and every use

1-800-255-5387

- Lubricate all coupling components at a minimum of 90 day intervals

- Do not bind-up (Jackknife) any application as stresses can cause damage to products
- or components, resulting in failure and detachment of the trailer while in use
- PREMIER-MFG.COM



DRAMBAR EYES

WW Will



HIP

Drawbar Eyes

Induction Through-Hardening

Induction Through-Hardened Drawbar Eyes and what this means to you ...

Premier's practice of **Induction Through-Hardening** all* Drawbar Eyes benefits you, the end user, by dramatically extending its life. Unlike other methods of heat treatment, Premier's Induction Hardening method doesn't just harden the outer surface, it hardens all the way through the eye loop. This process gives Premier Drawbar Eyes excellent wear resistance that lasts year after year and increases the service life of the eye loop.

*Weld-On model 2 and Bolt-On Adjustable Eyes 127 & 127F (Premalloy) are the only Premier Drawbar Eyes that are not Induction Hardened.

Slack Reducing Drawbar Eyes

The Slack Reducing Drawbar Eyes work to maintain a tight fit between the drawbar eye loop and pintle hook. The snug fit improves the ride & handling while reducing wear for increased service life.



Slack Reducing Drawbar Eyes are available in Bolt-On, Weld-On and Swivel models. Review the appropriate models for further details of slack reducing options.

They can be used with either a standard type 24 (#281) or 30 (#282) Air Chamber (page 74), or Premier model 500 Mechanical Slack Adjuster (page 75).

Drawbar Eye - to - Wear Gage Cross Reference

Our **Wear Gages** were designed to identify wear by measuring the cross-section of drawbar eye loops and coupling pintle hooks. 18% wear indicates that the product should be replaced as soon as possible. At 20% wear, the product is no longer in usable condition and must be taken out of service immediately and replaced (see pg 73).

Drawbar Eye	Wear Gage #	Drawbar Eye	Wear Gage #	Drawbar Eye	Wear Gage
2	n/a	107	14005 & 14032	300/300HD	14032
3	14002	108	14005 & 14032	304	14005, 14035
4	14005	110	14005 & 14032	305	14032 & 14008
5	14005 & 14008	123	14005	307	14032
6	14032	126	14005 & 14032	309	14032 & 14008
6A	14032	127/127F	14005 & 14032	405	14032 & 14008
8	14005	200	14005	405SE	14032 & 14008
11	14002	200L	14005	407SE	14032 & 14008
20	14005	203	14032 &14008	238DB	14005
21	14005	205	14005 & 14032	245DB	14005
22	14005	207	14005	245DB-3	14005
23	14005				


IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER DRAWBAR EYES

- Never attempt weld repair of damaged or worn drawbar eyes
- Slack reducing drawbar eyes must be used with an air service chamber or #500 slack adjuster
- Only Grade-8 fasteners properly torqued should be used when attaching bolton drawbar eyes
- Clean and inspect drawbar eyes and eye assemblies for damage or excessive wear before each and every use

Structure to which eye is attached must be of sufficient strength to withstand load rating of eye

1-800-255-5387


- All welds for attaching eye should be done by a certified welder skilled in structural welding
- Never attempt to use a swivel-type drawbar eye with a swivel-type coupling
- Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use
- Do not apply lubricants to the drawbar eye loop
- AND ADDRESS REAL PROVIDED AND ADDRESS A





- slack adjuster
- Clean and inspect drawbar eyes and eye assemblies for damage or excessive
- wear before each and every use
- Do not apply lubricants to the drawbar eye loop

rating of eye All welds for attaching eye should be done by a certified welder skilled in structural welding

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use








Do not apply lubricants to the drawbar eye loop

or components, resulting in failure and detachment of the trailer while in use


1-800-255-5387





wear before each and every use Do not apply lubricants to the drawbar eye loop

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER WELD-ON DRAWBAR EYES

- Never attempt weld repair of damaged or worn drawbar eyes Slack reducing drawbar eyes must be used with an air service chamber or #500
- slack adjuster Clean and inspect drawbar eyes and eye assemblies for damage or excessive
- wear before each and every use
- Do not apply lubricants to the drawbar eye loop


Structure to which eye is attached must be of sufficient strength to withstand load rating of eye

All welds for attaching eye should be done by a certified welder skilled in structural welding

- Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use


1-800-255-5387





PREMIER-MFG.COM


Bolt-On Drawbar Eyes



1-800-255-5387



Bolt-On Drawbar Eyes



Slack reducing drawbar eyes must be used with an air service chamber or #500 slack adjuster

Do not apply lubricants to the drawbar eye loop

Clean and inspect drawbar eyes and eye assemblies for damage or excessive wear frequently - Structure to which eye is attached must be of sufficient strength to withstand load rating of eye


Only Grade-8 fasteners properly torqued should be used when attaching bolt-on drawbar eyes

- Do not bind-up (Jackknife) any application as stresses can cause damage to products or

components, resulting in failure and detachment of the trailer while in use




Bolt-On Drawbar Eyes



- Only Grade-8 fasteners properly torqued should be used when attaching bolt-on drawbar eyes
- Do not bind-up (Jackknife) any application as stresses can cause damage to products or
- components, resulting in failure and detachment of the trailer while in use



Swivel Drawbar Eyes



Do not apply lubricants to the drawbar eye loop Clean and inspect drawbar eyes and eye assemblies for damage or excessive wear before each and every use


1-800-255-5387

products or components, resulting in failure and detachment of the trailer

PREMIER-MFG.COM

while in use

Swivel Drawbar Eyes



405 Pushrod Options

Standard Pushrod Lengths:

- 405L: 415A Pushrod 17 1/4 in. (438 mm), right-hand thread
- 405LL: 405L with left-hand threads on pushrod
- 405S: 415 Pushrod 15 1/2 in. (394 mm), right-hand thread
- 405SE: 415A Pushrod 17 1/4 in. (438 mm), right-hand thread
- 405SL: 405S with left-hand threads on pushrod

Optional Left-Hand Threaded Pushrods:

- 415L: 15 1/2 in. (394 mm), left-hand thread
- 415AL: 17 1/4 in. (438 mm), left-hand thread

Notes:

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SWIVEL DRAWBAR EYES

- Never attempt weld repair of damaged or worn drawbar eyes
- Never attempt to use a swivel-type drawbar eye with a swivel-type coupling
- Slack reducing drawbar eyes must be used w/an air service chamber or #500 slack adjuster Do not apply lubricants to the drawbar eye loop
- Clean and inspect drawbar eyes and eye assemblies for damage or excessive wear before
- each and every use

- Assembly to which eye is attached must be of sufficient strength to withstand load rating of eye

 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387








FRONT END HOUSINGS & HINGE ASSEMBLIES




Front End Housings





Front End Housings



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER FRONT END HOUSINGS

SECTION A-A

Never attempt weld repair of damaged or worn drawbar eyes or front end housings
Clean and inspect drawbar eyes and eye housings for damage or excessive wear before each and every use

SECTION A-A


 All welds should be performed by a certified welder skilled in structural welding practices

1-800-255-5387

Drawbar structure as well as welds attaching front end housing to drawbar must be of sufficient strength to withstand the load rating of the drawbar eye Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

SECTION A-A

Front End Housings




All welds should be performed by a certified welder skilled in structural welding practices

1-800-255-5387


products or components, resulting in failure and detachment of the trailer while in use





1-800-255-538









PREMIER-MFG.COM

<section-header><text></text></section-header>	1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
SPECIFICA	
Max. Gross Trailer Weight (pair):150,000 lbs.(68,039 (26.8 kg)Unit Weight (pair):59.2 lbs.(26.8 kg)Bushing Replacement:934A (Poly) Tapered 4 1/4 in.(108 mm) (108 mm) Length:2 1/4 in.(108 mm) (57 mm)	
IMPORTANT GUIDELINES THAT APPLY - Never attempt weld repair of damaged or worn hinge components - Clean and inspect hinge assemblies for damage or excessive wear before each and every use	 TO ALL PREMIER HINGE ASSEMBLIES The mounting structure the hinges are welded to must be of sufficient strength to withstand load ratings of hinges Do not bind-up (Jackknife) any application as stresses can cause damage to products

welding






PREMIER MANUFACTURING CO.


CAISTONA MOUNTING

DOLLY & MULTI-USE JACKS

O







- Never operate jack on uneven ground or where there is a chance of the lifted load shifting
- Never place more of a load on jack or caster which is greater than the lowest rated capacity

 Lubricate jack and check jack and caster assembly for damage or worn components frequently
 Do not bindum (lackknife) any application as stresses can cause damage to products o

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use



600 Jiffy Jack



Premier's 600 Series Jiffy Jacks are time savers by allowing the jack to be lowered to the ground or raised into the retracted position without having to crank the handle, see example below. Premier pioneered this design with speed of use as the focal point. The result is a jack that simply outperforms others in its class. The 600 series jiffy is the jack of choice for many fleets around the world.

- "Jiffy Quick Release" for instant, one-lever lowering and retracting of the leg without cranking.
- Quick action, spring-activated, folding handle that seats in a positive position for travel. This keeps the handle short, compact, and out of the way.
- DOM inner and outer tubes provide a strong precision fit, reducing penetration of outside contaminants.
- Oil cup for convenient lubrication of power screw.
- Custom mounting options allow mounting plate to be factory welded anywhere on the outside tube, or shipped loose for customer installation (available on most models).

Capacity: 5,000 lbs. (2,268 kg) operational, 10,000 lbs. (4,536 kg) static. Refer to caster chart for caster limitations, page 70.

Models Available:

See Jack Selection Guide on page 67 for additional options

Series	Travel	Base	Overall Height*
600	12 in. (305 mm)	726, 729	26 1/16 in. (662 mm)
600P	12 in. (305 mm)	726,729	26 1/16 in. (662 mm)
600	15 in. (381 mm)	726, 729	29 5/8 in. (752 mm)
600P	15 in. (381 mm)	726,729	29 5/8 in. (752 mm)

*(Retracted, Includes handle.)

Caster Options: See Caster Chart on page 70.

Jiffy Quick Release


Optional Accessories:

688 Swivel Mount: Helps lift jack up and out of harm's way when traveling (see page 69).


Shock Absorption Assembly: Reduces potential for jack damage when sudden drop-type loads are applied.




The "Jiffy Quick Release" option for our 600 series jacks enables the user to rapidly lower and raise the leg with one quick motion.



slight pressure on the caster plate, turn the **Quick Release** Lever. Inner jack tube can now be quickly extended to the ground.



Once caster is to the ground, only a few cranks of the handle will raise the load to the desired position. Handle will spring back to stored position once released.



Once the load has been removed from the jack, you can just as quickly return the jack to its fully retracted position.

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER JACKS

- Never operate jack on uneven ground or where there is a chance of the lifted load shifting
- Never place more of a load on jack or caster which is greater than the lowest rated capacity

1-800-255-538

- Lubricate jack and check jack and caster assembly for damage or worn components frequently

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

700 Standard Jack



The Premier 700 Standard Jack has been engineered and built to the same stringent specifications as our 600 Jiffy Jack. Designed for long life with minimal maintenance, the 700 is easily adapted to nearly any application.

- Quick action, spring-activated, folding handle that seats in a positive position for travel. This keeps the handle short, compact, and out of the way.
- DOM inner and outer tubes provide a strong precision fit, reducing penetration of outside contaminants.
- Tube support collar on outside tube for added strength.
- Oil cup for convenient lubrication of main bearing and power screw.
- Custom mounting options allow mounting plate to be factory welded anywhere on the outside tube, or shipped loose for customer installation.

Capacity: 5,000 lbs. (2,268 kg) operational, 10,000 lbs. (4,536 kg) static. Refer to caster chart for caster limitations, page 70.

Models Available:

See Jack Selection Guide on page 67 for additional options

Series	Travel	Base	Overall Height*
700	15 in. (381 mm)	726, 729	23 5/16 in. (592 mm)
700P	15 in. (381 mm)	726, 729	23 5/16 in. (592 mm)
*/			

*(Retracted, Includes handle.)

Caster Options: See Caster Chart on page 70.

Optional Accessories:

688 Swivel Mount: Helps lift jack up and out of harm's way when traveling (see below).

Shock Absorption Assembly: Reduces potential for jack damage when sudden drop-type loads are applied.

Model 700P-15-729


Swivel Mount Options

688, 688HD & 688US Swivel Mounts: Swivel Mounts allow for the jack to be rotated up, out of harm's way, as shown below.



688: Swivel Mount Assembly 689B: Pin & Cable Assembly

688: May be ordered separately or in place of standard mounting plate on any Premier Jack. (Bolt hole centers: 3 3/8 in. (86 mm) x 5 1/4 in. (133 mm) x 17/32 in. (13 mm) I.D.) 688HD: Same general design as our 688 above, but in a heavy-duty version. 688US: This is our Universal version of the 688. The 688US easily adapts to existing jacks that already have the standard mounting plate installed.



688CT: Inside tube and weld-on channel mount

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER JACKS

- Never operate jack on uneven ground or where there is a chance of the lifted load shifting
- Never place more of a load on jack or caster which is greater than the lowest rated capacity

Lubricate jack and check jack and caster assembly for damage or worn components frequently

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387



800 Utility Jack



Premier's 800 Utility Jack was designed to accommodate light to medium duty applications.

- Quick action, spring-activated, folding handle that seats in a positive position for travel. This keeps the handle short, compact, and out of the way.
- Strong, precision fit square tubing helps reduce penetration of outside contaminants.
- Tube support collar on outside tube for added strength.
- Oil cup for convenient lubrication of power screw.
- Custom mounting options allow mounting plate to be factory welded anywhere on the outside tube, or shipped loose for customer installation.

Capacity: 2,500 lbs. (1,134 kg) operational, 5,000 lbs. (2,268 kg) static. Refer to caster chart (below) for caster limitations.

Models Available:

See Jack Selection Guide on page 67 for additional options

Series	Travel	Base	Overall Height*
800P	15 in. (381 mm)	829	23 1/8 in. (587 mm)

*(Retracted, Includes handle.)

Caster Options: 620, 620P, 623

Optional Accessories:

688 Swivel Mount: Helps lift jack up and out of harm's way when traveling (see page 69).

Model 800P-15-829

Caster Options

Jack assemblies are to be fully retracted during highway operation. Capacity ratings apply only to manual operation at less than 5 mph (8 kph). Caster assemblies determine actual capacity of jack.

Caster Type	Series	Capacity	Overall Height	Wheel Size	Unit Weight
	620	1,200 lbs. (544.3 kg)	7 1/4 in. (184 mm)	6 in. (152 mm)	10 lbs. (4.5 kg)
a	620P	1,200 lbs. (544.3 kg)	7 1/2 in. (191 mm)	6 in. (152 mm)	7 lbs. (3.2 kg)
Steel	637**	1,200 lbs. (544.3 kg)	7 1/4 in. (184 mm)	6 in. (152 mm)	11 lbs. (5.0 kg)
	745*	1,400 lbs. (636.4 kg)	9 1/2 in. (241 mm)	8 in. (203 mm)	12 lbs. (5.5 kg)
	*Not recommende	d for 600 Series Jiffy Jacks			
Molden Rubber	623	800 lbs. (362.9 kg)	7 1/4 in. (184 mm)	6 in. (152 mm)	6 lbs. (2.7 kg)
	746**	800 lbs. (362.9 kg)	10 1/8 in. (257 mm)	8 in. (203 mm)	11 lbs. (5.0 kg)
Pneumatic	720**	390 lbs. (176.9 kg)	13 in. (330 mm)	10 in. (254 mm)	14 lbs. (6.4 kg)
	**Not recommend	ed for 800 Series Jacks			

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER JACKS

 Never operate jack on uneven ground or where there is a chance of the lifted load shifting Lubricate jack and check jack and caster assembly for damage or worn components frequently


Never place more of a load on jack or caster which is greater than the lowest rated capacity

1-800-255-5387

 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

Dolly and Multi-Use Jacks

The Jack Replacement Parts illustrated should accommodate most repair requirements. Complete inner and outer tube assemblies are also available. Contact Premier for more information.



- Never operate jack on uneven ground or where there is a chance of the lifted load shifting
- Never place more of a load on jack or caster which is greater than the lowest rated capacity

Lubricate jack and check jack and caster assembly for damage or worn components frequently

Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use





2



11/5 ... שני אוני בס





PREMIER-MFG.COM

200

Wear Gages



Gage	Description
14038:	2 11/16 in. (68 mm)
14000:	Complete Gage Kit (includes all items below)
14020:	2 5/8 in. (67 mm)
14017:	2 1/4 in. (57 mm)
14029:	Fleet Gage Kit (includes items below)
14026:	3/8 in. (10 mm) (Latch Gage)
14014:	2 1/8 in. (54 mm)
14011:	2 in. (51 mm)
14008:	1 3/4 in. (44 mm)
14032:	1 11/16 in. (43 mm)
14005:	1 5/8 in. (41 mm)
14035:	1 9/16 in. (40 mm)
14002:	1 1/2 in. (38 mm)

To determine wear limits, Premier created Wear Gages that help judge the useful life of couplings and drawbar eyes. Available as a complete kit or individually, these gages are easy to use and are a must for maintenance managers and safety personnel.

In accordance with Premier and the Federal Motor Carrier Safety Regulations, these were designed to identify wear at the critical percentages of 18% and 20%, by measuring the cross-section of coupling hooks (horn) and drawbar eye loops. 18% wear indicates that the product should be replaced as soon as possible. At 20% wear, the product is no longer in usable condition and must be taken out of service immediately and replaced. The latch gage bar measures the gap space between the top of the coupling hook and the closed latch. If the 3/8" latch gage bar can pass between this region, then the latch components should be considered worn past safe limits and replaced. Please note that these wear gage specifications are in accordance with Premier Mfg. Co. and the Federal Motor Carrier Safety Regulations (refer to other manufacturer's specifications for wear limits on their products).

Gages can be purchased individually or in two kit options.

See pages 7 & 46 for Cross Reference Charts.



Drawbar Guides

Premier's Drawbar Guides act as an aid to operators when hooking up equipment. These guides are cast from high strength steel and are easily installed by welding to the rear cross member.

Guides can be purchased individually or as complete sets.

Guide	Couplings Used With
378:	360, 370, 370B, 570, 770, 2300 & 2300B
378M:	100, 270
438:	100-3, 100-4, 100-4H, 1400, 1400H, 470, 470H, 2200, 2400 & 2400H

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER ACCESSORIES

- Always check parts for proper operation prior to placing in service
- Clean and lubricate accessories (where applicable) frequently
- Never attempt weld repair or other repair to damaged or defective Premier accessories

- Only use Premier manufactured or authorized accessories or parts in or on Premier products

Clean and inspect accessories for damage or excessive wear before each and every use - Do not bind-up (Jackknife) any application. Stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

1-800-255-538



281 / 282 Air Chambers



SPECIFICATIONS

Premier Air Chambers are definitely <u>not</u> your typical air chambers. Ours are built to last in the rigorous service of coupling and drawbar eye connections.

- 281 (Type-24) Air Chamber (8" pushrod): Maximum Force at 100 psi: 2,400 lbs. (10.68 kN) Unit Weight: 9.1 lbs. (4.1 kg)
- 281L (Type-24) Air Chamber (12" pushrod): Maximum Force at 100 psi: 2,400 lbs. (10.68 kN) Unit Weight: 9.6 lbs. (4.4 kg)
- 281-Custom (Type-24) Air Chamber (custom pushrod <8"): Maximum Force at 100 psi: 2,400 lbs. (10.68 kN) Minimum Order Quantity: 50
- 281L-Custom (Type-24) Air Chamber (custom pushrod 8"-12"): Maximum Force at 100 psi: 2,400 lbs. (10.68 kN) Minimum Order Quantity: 50
- 282 (Type-30) Air Chamber (8" pushrod): Maximum Force at 100 psi: 3,000 lbs. (13.34 kN) Unit Weight: 9.8 lbs. (4.4 kg)

271 – Series Thimbles



SPECIFICATIONS

Premier's thimbles are highly wear resistant. They are used on the end of the Pushrod of an air chamber that contacts the Slack Adjustment Shoe in Premier air take up couplings.

271: 7/8 in. (22 mm) x 2 3/4 in. (70 mm) (Standard) **271B:** 7/8 in. (22 mm) x 4 3/8 in. (111 mm) (Optional) **271C:** 7/8 in. (22 mm) x 5 1/2 in. (140 mm) (Optional) **271D:** 7/8 in. (22 mm) x 6 1/2 in. (165 mm) (Optional) **271H:** 7/8 in. (22 mm) x 2 1/8 in. (54 mm) (Optional)



Standard Brackets (2 3/4 in. (70 mm) overall length):

- 267: For use with: 270, 2200, Saf-Tite 100 & 820 Slack Reducing Couplings
- **467:** For use with: 360, 370, 470, 470H, 2300, 2400, 2400H, 1400, 1400H & Saf-Tite 100-3, 100-4, 100-4H Slack Reducing Couplings
- 767: For use with: 780, 880 & 2880 Slack Reducing Couplings

Non-Standard Brackets:

- **267F:** 4 5/8 in. (117 mm) overall length (same couplings as 267)
- **467F:** 5 1/2 in. (140 mm) overall length (same couplings as 467)
- 267H, 467H: 3/4 in. (19 mm) overall length (same couplings as 267 & 467 respectively)

47 - Series Couplers



SPECIFICATIONS

Used to connect Air Chamber Pushrod to Pushrod of Drawbar Eye.

47: 3 5/8 in. (92 mm) long **Thread:** 5/8 in.-18 NF to 3/4 in.-16 NF

47L: 3 5/8 in. (92 mm) long **Thread:** 5/8 in.-18 NF to 3/4 in.-16 NF (left-hand)

47SPL: 6 in. (152 mm) long **Thread:** 5/8 in.-18 NF to 3/4 in.-16 NF

Optional Accessories:

281J Jam Nut: 5/8 in. - 18NF used to secure coupler in position on 281 or 282 Air Chamber pushrod.

IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER ACCESSORIES

- Always check parts for proper operation prior to placing in service

- Clean and lubricate accessories (where applicable) frequently
- Clean and inspect accessories for damage or excessive wear before each and every use
- Never attempt weld repair or other repair to damaged or defective Premier accessories


 Only use Premier manufactured or authorized accessories or parts in or on Premier products

- Do not bind-up (Jackknife) any application. Stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

PREMIER-MFG.COM

1-800-255-5387

Bolt Kits




These individually packaged bolt kits make the hardware selection for your coupling and/or drawbar eye fast and easy.

Bolt kits 501 through 508 use coarse threaded Grade-8 fasteners and Grade-C crimp style locknuts for a strong and secure coupling or drawbar eye mounting system.

Bolt Kit 511 uses coarse threaded L9 Grade bolts. * * 159 Bolt Kit has fine threaded Grade-8 fasteners.


SPECIFICATIONS				
Part #	For use with:	Includes:	Maximum Mounting Structure Thickness:	
501:	270, 2200, 100	Bolts (2) 2 1/2 in. (2) 2 3/4 in., Locknuts (4)	1/2 in. (13 mm)	
502:	360, 370, 780, 2300, 100-3	Bolts (4) 2 1/2 in. (2) 2 3/4 in., Locknuts (6)	1/2 in. (13 mm)	
503:	127, 127F, 370B, 570, 580J, 2300B	Bolts (6) 2 1/2 in., Locknuts (6)	1/2 in. (13 mm)	
504:	570	Bolts (6) 2 in., Locknuts (6)	1/2 in. (13 mm)	
505:	770	Bolts (5) 2 1/2 in. (2) 2 3/4 in., Locknuts (7)	1/2 in. (13 mm)	
507:	200, 200L, 300, 480, 580, 590, 690, 890C	Bolts (4) 2 3/4 in., Locknuts (4)	1/2 in. (13 mm)	
508:	470, 470H, 2400, 2400H, 100-4, 100-4H, 1400, 1400H	Bolts (6) 2 1/2 in. (2) 2 3/4 in., Locknuts (8)	1/2 in. (13 mm)	
509:	820	Bolts (4) 2 3/4 in., (2) 3in., Locknuts (4)	1" (25 mm)	
511:	2880, 880	Bolts (6) 3 1/2 in., Locknuts (6)	1 5/8 in. (41 mm)	
**159:	150, 160, 240	Bolts (4) 2 in., Lock washer (4), Hex nut (4)	3/4 in. (19 mm)	

** 159 Kit has fine threads, uses lock washers and standard nuts.



500 Mechanical Slack Adjuster

A complete mechanical slack adjustment device intended for use with any Premier slack adjusting drawbar eye. The 500 is designed to be used in place of 281 or 282 air chambers. No plumbing of air lines and simple operation make for an easy install and minimal maintenance. Unit weight 9.3 lbs. (4.2 kg).



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER ACCESSORIES

Always check parts for proper operation prior to placing in service

· Clean and lubricate accessories (where applicable) frequently

Clean and inspect accessories for damage or excessive wear before each and every use

Never attempt weld repair or other repair to damaged or defective Premier accessories

- Only use Premier manufactured or authorized accessories or parts in or on Premier products

Do not bind-up (Jackknife) any application. Stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387








Designed for superior strength, the 165 is a one-piece, solid steel casting, adjustable mount for 2 in. receiver-type connections.

It allows for three different vertical height positions for mounting Premier 150 & 160 couplings (pages 33 & 34).



 Maximum Gross Trailer Weight:
 10,000 lbs.
 * (4,536 kg)

 Maximum Tongue Weight:
 1,000 lbs.
 * (454 kg)

 Unit Weight:
 11 lbs.
 [5 kg]


 Pin Diameter:
 5/8 in.
 (16 mm)

*Stated capacities to be reduced accordingly if receiver receptacle unit has less capacity.



Like our 165 Receiver, the 166 is also a single, solid steel casting, adjustable mount receiver, except it is used in 2 1/2 in. receiver-type connections.

It allows for three different vertical height positions for mounting Premier 150 & 160 couplings (pages 33 & 34).



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER RECEIVERS

- To be attached by 5/8 in. pin only
- Only Grade-8 fasteners properly torqued should be used to attach couplings
- Never attempt weld repair of damaged or defective receivers or receiver receptacles

1-800-255-5387

- If receiver receptacle has a less capacity do not exceed it

Clean and inspect accessories for damage or excessive wear before each and every use
 Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

150 Coupling Balls



Coupling Balls designed exclusively to fit Premier's 150 Coupling (see page 33).

Part #	Couplings Used With
100PK	100, 100-3, 100-4, 100-4H
130PK	130, 240, 240K
135PK	135NT, 235NT
150PK	150, 150-1, 160
270PK	270
370PK	370, 370B, 570, 770
470PK	470, 470H
480RK	480
580RK	580, 580J
690LRK	690L
700RK	700 Jack
880RK	880
890PK	890CL, 890CR
2000PK	1400, 1400H, 2200, 2300, 2300B, 2400, 2400H, 2880
2000PK-EL	2200, 2300, 2300B, 2400, 2400H, 2880
2200PK-ELL	2200ELL

SPECIFICATIONS

Product #	Ball Diameter	Maximum GTW
155 Ball	2 in. (51 mm)	10,000 lbs. (4,536 kg)
156 Ball	2 5/16 in. (59 mm)	10,000 lbs. (4,536 kg)


All sizes have $1 \frac{1}{4}$ in. diameter shaft and come standard with a $1 \frac{1}{4}$ in. nylon locknut (157).



Parts Kits & Repair Kits

Parts Kits & Repair Kits, they are one and the same in that they have all the parts needed to perform a complete rebuild for the given product model #. In a day and age when efficiency and liability are paramount, do yourself a favor and purchase a complete kit to service your coupling and sleep better at night. All of Premier's most popular models have a complete kit available, so please consult this cross reference chart to find the single part # to order your kit.

2000PK Parts Kit



IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER HITCH BALLS AND TOW HOOKS

- Only Grade-8 fasteners properly torqued should be used to attach tow hooks
- Never attempt weld repair of damaged or defective hitch balls or tow hooks
- Always check parts for proper operation prior to placing in service

Clean and inspect accessories for damage or excessive wear before each and every use
Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

1-800-255-5387



Premier's Safety Chain Hangers are what much of the trucking, utility, and construction industry have been requesting for many years - a strong, reliable, and easy to install hanger system. They are available in two sizes and styles. **9 Safety Chain Hanger** MGTW: 30,000 lbs. (13,608 kg) Weight: Ø3/4 2.4 lbs. (1.09 kg) 31/2 21/16 11/16 PREMIER SECTION A-A - 21/4 -51/2 **10 Safety Chain Hanger** MGTW: 90,000 lbs. (40,823 kg) Weight: Ø11/4 9.7 lbs. (4.4 kg) 13/16 PREMIER SECTION A-A 3 3/4 93/16 **10A Safety Chain Hanger** 11/2 1 1/2 61/4 3 3/4 MGTW: 90,000 lbs. (40,823 kg) Weight: 9.0 lbs. (4.08 kg) PREMIER 10A V 7/18 SECTION A-A 9 1/4 12L / 12R Tow Hooks Ø3/4 Premier's 12L and 12R tow hooks have 🕅 been around for many years. Made of high strength cast steel, these hooks are not only tough but easy to install. Capacity of each hook is 25,000 lbs. 5/8 7 5/8 (11,339 kg). 8 1/2 IMPORTANT GUIDELINES THAT APPLY TO ALL PREMIER SAFETY CHAIN HANGERS

- Hangers are to be attached by welding only
- Never attempt weld repair of damaged or defective chain hangers
 Welding should only be performed by a certified welder skilled in structural welding practices

1-800-255-5387

- Always check parts for proper operation prior to placing in service

Clean and inspect accessories for damage or excessive wear before each and every use
Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

Glossary

- A-Dolly (Dolly, Converter Dolly) A single or double axle unit with a fifth wheel and drawbar eye point of attachment that converts a semi trailer to a full trailer.
- Air Adjusted (Coupling or Drawbar Eye) A coupling or drawbar eye with an air take up system that reduces slack at the connection, via pressure from an air service chamber.
- **Air Chamber** A device that encompasses a bladder and spring that when air is supplied extends and when air is taken away it retracts. Used as part of the slack reducing system for a coupling or drawbar eye.

Application – The configuration of transportation equipment and how and where it is used.

Bind-Up (Binding) – see jackknife.

- **C-Dolly** A convertor dolly that has two points of attachment equally spaced from the vehicle centerline, which will not allow any turning to occur at the connections.
- **Chamfer** The beveling of flat or circular edge, typically done at a 45 degree angle.

Converter Dolly – see A-dolly.

- **Coupling (Hitch or Pintle Hook)** A device with a latch system that, when used in combination with a drawbar eye, connects a towed vehicle to the towing vehicle.
- **Coupling (Hitch) Ball** A spherical ball atop a post that connects to a trailer with a spherical socket coupler. Typically used in passenger vehicle applications.

Dolly - Generic description for an A-dolly or C-dolly.

Dolly Jack - A mechanical device for lifting, used for holding up the front end of a dolly when not coupled to a towing vehicle.

Drawbar - see front end.

Drawbar Eye (Lunette) – A ring shaped object used in combination with a coupling to connect a towed vehicle to the towing vehicle.

Drawbar Eye Loop – The ring shaped portion of the drawbar eye.

Drop Pintle Coupling – A coupling with a pintle (hook) that rotates downward when the latch system is opened, allowing the drawbar eye to be disconnected.

Dynamic Load – A type of load that changes in the direction or degree of force during operation.

Eye X-Section - The diameter dimensions of the tip of a drawbar eye loop measured in the horizontal and vertical planes.

Fastener - Hardware that mechanically joins or affixes two or more objects together (a nut and bolt).

Front End – The front end of a trailer or convertor dolly.

- **Front End Housing** A device that is welded to the front of a trailer or dolly that allows the installation of a swivel drawbar eye.
- Full Trailer Any trailer other than a pole trailer that is constructed so that no part of its weight, except for the towing device, rests upon the towing vehicle.
- **GTWR (Gross Trailer Weight Rating)** The value specified by the manufacturer as the maximum allowed loaded weight of a trailer.
- **GVWR (Gross Vehicle Weight Rating)** The value specified by the manufacturer as the maximum allowed loaded weight of the vehicle.

Hinge (Hinge Assembly) - A device that allows the front end of a trailer or dolly to articulate in the vertical plane.

Hitch – see coupling.

Hook - see pintle.

Horn – see pintle.

Induction Hardening – A heat treat procedure that allows for a desired area of the part to be hardened, while other areas are unaffected.

Jack - A mechanical device used to lift heavy loads.

Jackknife – The over-articulation of the coupling connection that results in binding at the coupling to drawbar eye connection, or between the structures of the towing and towed vehicle.

1-800-255-5387



Glossary

Latch – A combination of parts on a coupling body that open and close, allowing the drawbar eye to be contained on the pintle.

Load Specifications – The weight capacity of a device or vehicle.

Lunette Eye – see drawbar eye.

Maintenance – A regularly scheduled interval of cleaning, inspecting and lubricating of coupling and drawbar eye components to preserve their operation and life expectancy.

MGTW (Maximum Gross Trailer Weight) - see GTWR.

Mounting Surface – The area a coupling, drawbar eye or hinge assembly attaches to.

Off-Road – Use of a vehicle on any surface other than pavement or concrete.

Operating Conditions – The environment a vehicle is operated in.

Out-Of-Service - No longer suitable for use.

Over-The-Road – Use of a vehicle on pavement or concrete roads.

Pintle – The hook section of a coupling device that a drawbar eye loop attaches to.

Pintle Hook – see coupling.

Premalloy – Premier's longest wearing proprietary material, used in some models of couplings and drawbar eyes.

Pushrod - A rod that connects the air chamber to the shoe in slack reducing couplings or drawbar eyes.

Saddle Area – The region of a coupling where the drawbar eye rests in the vertical load direction.

Safety Chain(s) or Cable – A backup safety device that must be of sufficient strength to contain a trailer if an accidental disconnect of the coupling and drawbar occurs (mandatory in North America).

Saf-Tite – Premier's highest strength couplings, at a value.

Semitrailer – Any trailer other than a pole trailer that is constructed so that some part of its weight rests upon the towing vehicle.

Shock Load - see dynamic load.

- **Shoe** The portion of an air take up system that contacts the drawbar eye loop (coupling style) or pintle hook (drawbar eye style).
- Slack Reducing System Specifically designed by Premier to improve drivability of the connected vehicles and reduce wear at the coupling to drawbar eye connection. This is done by applying a clamping force at the connection that removes all free play, thus drastically reducing the slamming back and forth of the drawbar eye loop on the coupling pintle (horn). Less movement means a more comfortable ride as well as longer component life.

Static Load – The weighed load of a vehicle when not in motion.

Swivel Coupling – A coupling with a shank that resides in bores and allows for rotation about the longitudinal axis of the vehicle. It is typically used in off-road applications, and never used with a swivel drawbar eye.

Swivel Drawbar Eye – A drawbar eye with a shank that resides in bushings and allows for rotation about the longitudinal axis of the vehicle. It is typically used in off-road applications, and never used with a swivel coupling.

Tongue - see front end.

Tongue Weight – The weight of the trailer or dolly in the vertical plane that is applied to the coupling.

Torque – The measured value of a force applied to produce rotation about an axis, typically measured in foot or inch pounds.

Tow Bar - see front end.

Tow Hook - A device used to temporarily allow one vehicle to pull another, usually used in conjunction with a cable or strap.

Towed Vehicle – A vehicle being pulled by another vehicle, typically a trailer.

Towing Vehicle – The tractor or other type of vehicle pulling a trailer.

Trailer Hitch - see coupling.

Ultimate Latch Capacity – The maximum non-sustained load on a latch or upper coupling surface that contains the drawbar eye.

Wear Gages – Various tools used to measure wear and determine serviceability on a coupling hook, drawbar eye loop, or gap at the latch to hook interface.



Notes:



Notes:



PREMIER MANUFACTURING CO.

WARRANTY:

We warrant all Premier products to be free from defects in material or workmanship for one year. We will repair or replace, at our option, any Premier product which our examination reveals to be defective, provided that the product is returned to our factory, at Tualatin, Oregon transportation prepaid, within one year of purchase by the first retail purchaser. Our warranty does not extend to products which have been subject to misuse, neglect, improper installation, maintenance or application, nor does our warranty extend to products which have been repaired or altered outside of Premier's facility unless the repair or alteration has been expressly authorized in writing by Premier. *This warranty is in lieu of all other warranties, express or implied, and excludes warranties of merchantability, fitness for a particular purpose and otherwise, and in no event will Premier be liable for incidental, special, contingent or consequential damages.*

DISCLAIMER:

Although great care has been taken to ensure accurate information throughout this catalog, Premier Manufacturing Company must reserve the right to alter any information contained within. These changes include but are not limited to: dimensional changes, load capacity and availability of any part or assembly.

© 2022 Premier Manufacturing Company

1-800-255-538

All rights reserved. Any reproduction of the photographic images or any other portion of this catalog, including but not limited to the photo copying, or retention and/or storagein a retrieval system of any kind, is strictly prohibited without prior express written permission from Premier Manufacturing Company.



A DIVISION OF HIGH BAR BRANDS, LLC





PREMIER MANUFACTURING COMPANY 19500 SW Teton Ave, Tualatin, OR 97062 (503) 234-9202 | (800) 255-5387 www.PREMIER-MFG.com