



PREMIER
MANUFACTURING CO.
 THE FIRST NAME IN QUALITY COUPLINGS

WARNING!

Read This Sheet
 Before Installing
 467 Air Chamber Bracket
**467W WASHERS ARE
 REQUIRED**

WARNING!

Read This Sheet
 Before Installing
 467 Air Chamber Bracket
**467W WASHERS ARE
 REQUIRED**

467 Air Chamber Bracket Installation - Must Use Both 467W Washers

FIGURE #1

467 Air Chamber Bracket
 Correct Orientation




FIGURE #2





FIGURE #3



IMPORTANT:

Both of the supplied 467W Washers must be used when installing the 467 Air Chamber Bracket. Any substitution or use of non-Premier parts will VOID ALL PRODUCT WARRANTY.

Installation Procedure:

1. See Figure #1 to determine the upright, correct orientation of the 467 Air Chamber Bracket.
2. **NOTE:** In the upright position, the large radius of the bracket flanges will face downward.
3. Reference all Figures for correct placement of 467W Washers.
4. Install 467 Air Chamber Bracket with the two supplied 467W Washers in position, as shown in Figure #3.