



PREMIER
MANUFACTURING CO.

THE FIRST NAME IN QUALITY COUPLINGS

Installation, Inspection, Operation & Maintenance Guide



MODEL 440/440A & 455/455A HINGE ASSEMBLIES


IMPORTANT

Read these instructions completely before installing, using or attempting to repair this product. If you have any questions, call Premier at (800) 255-5387 or (503) 234-9202

SELECTING THE RIGHT EQUIPMENT

Whatever your application, selecting the proper equipment for the job is very important. Proper selection along with regular inspection and maintenance will help keep operating costs minimal while providing long life to each component. Below are general guidelines for selecting Premier Coupling and Drawbar Eyes. If you feel that your application is unique, please give Premier a call so that we may help you through the selection process.

Follow these four steps to ensure proper selection of Premier Couplings and Drawbar Eyes.



STEP 1: Determine "Gross Trailer(s) Weight"

"Gross Trailer(s) Weight" is usually determined by the Gross Vehicle Weight Rating (GVWR). This information is attached to the trailer manufacturer.

For "Double Trailer" configurations, only the rear trailer is considered when selecting your Premier Coupling or Drawbar Eye. In this example, a Coupling and Drawbar Eye with a "Gross Trailer Weight" rating of 40,000 lbs. (18,143 kg) would be the minimum rating acceptable for normal, over-the-road applications (see Tongue Weight section below).

Double Trailer Configuration



Example only, each application may vary and should be considered unique.

For "Triple Trailers", only the two most rearward trailers are considered in selecting your Premier Coupling or Drawbar Eye. In this example, a Coupling and Drawbar Eye with a "Gross Trailer Weight" rating of 80,000 lbs (36,287 kg) would be the minimum acceptable for normal, over-the-road applications. (see Tongue Weight section below).

Triple Trailer Configuration



Example only, each application may vary and should be considered unique.

STEP 2: Determine "Tongue Weight Capacity"

"Tongue Weight Capacity" is the maximum expected weight at the drawbar eye. Of a hinged drawbar is used, the maximum weight will be approximately 1/2 the overall drawbar weight. If a non-hinged drawbar is used and the actual tongue weight is not known, you can approximate the weight by multiplying the GVWR of the towed trailer by 15%. However, each application is unique and the best practice is to weight the tongue when the trailer is loaded to GVWR.



STEP 3: Consider Operating Conditions and Environments

Environments such as rough uneven roads or off-road use can dramatically increase shock loads to both drawbar eyes and couplings. In general, increasing the "Gross Trailer Weight" (Step 1:) and "Tongue Weight Capacity" (Step 2:) by a minimum of 25% will be sufficient for many applications. Even if an application is used off-road occasionally, the minimum increase necessary for Gross Trailer and Tongue Weight is 25%. Certain types of equipment and/or operating practices can also dramatically increase loads through equipment binding and/or improper loading practices. Of special concern is high tongue weight. However, each application is unique and every environment different, therefore your application may require more than 25%.

Once both "Gross Trailer(s) Weight" (Step 1:) and "Tongue Weight Capacity" (Step 2:) have been determined, evaluate your operating conditions and apply an appropriate margin of safety.

STEP 4: Browse Premier Product Catalog


Browse the Premier Product Catalog and refer to the "Specifications" section of each product. Be sure to review the "Understanding Premier Load Specifications" sections and "Coupling to Drawbar Eye Cross-Reference" sheet on the next couple of pages.



SELECTING THE RIGHT EQUIPMENT

Understanding Premier Load Specifications

Each Premier product undergoes extensive design and testing prior to being introduced. We use the latest in Computer Aided Design and Analysis Software as well as physical destructive tests. Premier's published load specifications are the maximum load a given product or part will withstand without failure. Premier's testing procedures closely follow the Society of Automotive Engineers (SAE) guidelines of Recommended Practice for testing Couplings and Drawbar Eyes (SAE J847 & J849).



Importance of Inspection and Maintenance

Safety is our #1 Priority: Through high quality designs and unsurpassed quality control procedures, Premier assures our customers that our focus on safety continues to be our #1 priority.

Scheduled Inspection & Maintenance: Regularly scheduled inspection and maintenance are essential for maintaining safe and efficient operations whether you are using Couplings, Drawbar Eyes, Jacks, Hinge Assemblies, or any other Premier product. Inspection and maintenance are necessary for proper function and will also keep repair costs to a minimum.

Technical Literature: Premier provides important literature to assist you with our products. We package and attach Installation, Inspection, Operation & Maintenance Guides, or Service Guides, to each of our major products. This literature is also available to view and/or print from our website at www.premier-mfg.com. These supply you with important information and help guide you through installation, inspection, operation, routine maintenance and part replacement.

Wear Gages: In accordance with the Federal Motor Carrier Safety Regulations, we created Wear Gages to assist you in determining the wear limits of Premier couplings and drawbar eyes. See details on catalog pages 7 & 75.

Additional Product Resources at Your Fingertips

Customer Service: We are always here to support you. Do you need additional information or assistance? Your phone calls are greeted by our courteous receptionist, during business hours. We have exceptional, personable Customer Service Reps for you to rely on. If you have product questions or want to place an order, you can speak directly with one of our experienced and knowledgeable Customer Service Representatives.

Sales Representatives: Would you like on site training or assistance? Contact one of our veteran Premier Sales Reps for more information about product training for your staff. Or be sure to visit with them at a Trade Show (see website for schedule).


www.premier-mfg.com: Our website is an informative resource at your fingertips. In addition to our Installation and Service Guides, you will find our Sales Representatives, distributor locations, online catalog pages, product specifications, how to select product, trade show schedule, and links to trucking resources.



SELECTING THE RIGHT EQUIPMENT

Coupling - to - Drawbar Eye, Cross Reference Chart



		DRAWBAR EYES																														
		2*	3	4	5	6/6A	8	11	20	21	22	23	107	108	110	123	127	200	200L	205	207	238DB	245DB	245DB-3	300/300HD	304	305	307	309	405	407SE	
COUPLINGS	16	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		
	24	•																														
	100†			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
	100-3†			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
	100-4†			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
	100-4H†			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
	130	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
	135NT		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•		•			
	140	•	•						•																							
	150			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	160	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	235NT			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	•		•		
	240		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	240K			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	270			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	335NTEL																					•		•	•	•	•		•			
	360			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	370			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	370B			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	470			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	470H			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	480			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	570			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	580	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	580J			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	690L			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	780			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
	790																					•		•	•	•	•	•	•			
820ELA			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
880																						•		•	•	•	•	•				
890/890C			•	•	•	•	•	•	•	•	•	•			•	•		•	•	•		•	•	•	•	•			•			
2200			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
2300			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
2400			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
2400H			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
2800																						•		•	•	•	•	•				

† Saf-Tite Product

* Industrial Application

CAUTION: Verify that both the coupling's and drawbar eye's rated capacities meet your application(s) requirements



MODEL 440/440A & 455/455A HINGE ASSEMBLIES


Specifications and Load Capacities

SAFETY WARNING


This product is designed for towing under normal conditions within the stated gross trailer weight capacity of the hinge assembly being used. Do not overload or abuse this product. Overloading or abuse may lead to property damage, severe injury, or death.

Max. Gross Trailer Weight (pair):	100,000 lbs.	(45,359 kg)
Bushing I.D.:	2 in.	(51 mm)
Bushing O.D.:	3 1/2 in.	(89 mm)
Bushing Length:	1 3/4 in.	(44 mm)
Model 440 Unit Weight (pair):	53.2 lbs.	(24.1 kg)
Model 455 Unit Weight (pair):	50 lbs.	(22.7 kg)

440/440A Standard Installation Drawing



455/455A Standard Installation Drawing



MODEL 440/440A & 455/455A HINGE ASSEMBLIES

Parts & Accessories

Parts included with 440/440A

- 351 Bolt & Nut (2)
- 424L/424R Housing
- 441 Bracket
- 442 Pin
- 445 Adjustable Shoe
- 447 Bolt (2)
- 448/448A Bushing (2)
- 653 Snap Ring (2)

Parts included with 455/455A

- 351 Bolt & Nut (2)
- 452L/452R Housing
- 441 Bracket
- 442 Pin
- 445 Adjustable Shoe
- 447 Bolt (2)
- 448/448A Bushing (2)
- 653 Snap Ring (2)

Bushing Replacements

- (Use ONLY Premier's Bushings):**
- 448 (Rubber) or 448A (Poly)

Installation

The 440/440A & 455/455A Hinge Assemblies are ONLY to be used and maintained with Premier parts. Any substitution or use of non-Premier parts in a 440/440A or 455/455A Hinge Assembly will VOID ALL PRODUCT WARRANTY.

Installation Procedure:

1. 440/440A & 455/455A Hinge Assemblies must be installed to comply with the Federal Motor Carrier Safety Regulations. Specifically, Section 393.70, Paragraph C: "Towing of Full Trailers." Prior to install or operation, consult with local, State and Federal agencies, as there may be additional applicable laws governing the installation and use of this product.
2. Prior to welding, Premier strongly suggests building a jig to properly locate the 424 Housings (for the 440/440A) or 452 Housings (for the 455/455A) and 441 Brackets. The jig should ensure the two Hinge Assemblies are of equal height above the ground, parallel and equidistant from the trailer centerline. Figure 1 shows a top view of two properly placed 440 Hinge Assemblies.
3. All welds used to install the 440/440A and 455/455A Hinge Assemblies must follow one of the three attached Welding Procedure Specifications; GMAW, SMAW or FCAW. Welding should only be performed by a certified welder skilled in structural welding practices.
4. All weld locations must be clean, paint free and void of any moisture, oil, grease, oxides or loose or thick scale.

Because 440/440A or 455/455A Hinge Assemblies operate in pairs, the installation instructions below are to be simultaneously followed for each hinge assembly.

424L/424R & 452L/452R Housing Installation:

5. The 424 Housings accommodate a front end structure consisting of 3" channel or square tubing. The large weld tab on the 424 Housings may be heated and bent outward 10° or inward 5° (see Figure 2) to conform to a wide range of front end angles. The 452 Housings accommodate a front end structure consisting of 2" x 4" rectangular tubing or channel. The large weld tab on the 452 Housings may be heated and bent inward or outward 10° to conform to a wide range of front end angles. Note that the weld tabs on both housings must be bent equally and when the install is complete, the two housings are to be equidistant from the trailer centerline and their bores aligned.
6. Fit-up, between the front end tube (or channel) and the mounting surface of the 424 or 452 Housings, must be flush, as Figure 3 demonstrates on a 424 Housing. Failure to have a flush fit prior to welding will cause the capacities to be negatively affected. Figures 3A and 3B show two possible examples of an improper fit-up that must be avoided.
7. Attach the 424 or 452 Housing to the front end tube with a minimum 3/8" fillet weld that encompasses the entire interface between the housing and tube as shown in Figure 3.



MODEL 440/440A & 455/455A HINGE ASSEMBLIES

Installation

441 Bracket Installation:

8. The two 441 Brackets must be equal in height above the ground, parallel, equidistant from the trailer centerline and their bases must be flush with the mounting structure surface. Misaligned brackets or a failure to have a flush fit with the mounting surface prior to welding will cause poor hinge operation as well as negatively affect their capacities.
9. Tack weld the 441 Brackets in place and test fit the 424 or 452 Housings. Before proceeding, make sure the centerlines and bores of the housings align with the centerlines and bores of the brackets.
10. Attach the 441 Bracket to the mounting surface with a minimum 3/8" fillet weld around the outer and inner surfaces of the bracket as shown in Figure 4.

440/440A & 455/455A Hinge Assembly after Welding

(440/455: Premier 448 Rubber Bushings only)

(440A/455A: Premier 448A Poly Bushings only)

11. Allow the finished structures to cool.
12. Loosen the two 447 Bolts in the 424 or 452 Housing far enough so they do not protrude into the housing bore.
13. Slide one of the two 448/448A Bushings, chamfered end first, into one side of the 424 or 452 Housing (see Figure 5 illustration of a 440 Hinge Assembly). Roughly 3/16" of the bushing should be sticking out of the housing.
14. From the other side of the 424 or 452 Housing that the 448/448A Bushing was placed, slide the 445 Shoe into the housing's bore with the shoe's outside curved surface adjacent to the two 447 Bolts. The shoe needs to slide in far enough for its internal rib to be in alignment with the housing's internal rib.
15. Place the other 448/448A Bushing, chamfered end first, into the 424 or 452 Housing.
16. Place the 424L & 424R Housings or 452L & 452R Housings into each 441 Bracket aligning the bores as much as possible.
17. Slide the 442 Pin through the aligned bores of the 441 Bracket and 424 or 452 Housing far enough so both snap ring grooves at the end of the pin are visible.
18. Attach the 653 Snap Rings into the grooves at each end of the 442 Pin and ensure the snap rings are fully seated in the grooves. Use caution when installing the snap rings and make certain not to over expand them as this will cause permanent damage to the snap rings.
19. Tighten the 351 Bolts to 80 ft-lbs of torque. These bolts compress the 441 Bracket, clamping the 442 Pin.
20. Torque the 447 bolts equally and test the hinge assemblies for desired rotational stiffness. If a stiffer hinge is desired, tighten both 447 Bolts until the desired stiffness is reached.
21. An "IMPORTANT WARNINGS!" sticker was enclosed. This must be attached to the front end, adjacent to the drawbar eye, visible for the end user to read.



MODEL 440/440A & 455/455A HINGE ASSEMBLIES

Installation

Figure 1
440





Figure 2
400



MODEL 440/440A & 455/455A HINGE ASSEMBLIES

Installation

Figure 3
440






Figure 4



Installation



Inspection/Operation/Maintenance

1. Visually inspect the hinge assembly for cracks, impact damage and/or deformation before each and every use. Do NOT use if any of these conditions exist.
2. Over time, slack may develop in the hinge assembly due to normal bushing wear. Therefore, clean and inspect every 90 days or sooner if your application dictates, and adjust or replace the bushings if slack is noted.
3. To check for bushing wear, place a crowbar near the center of the bracket adjacent to the housing. Apply pressure to the bar and visually test for free-play between either the bushing & the housing or the bushing & the taper pin. If free-play is noted tighten and/or replace bushing.
NOTE: Pulling forward or backward while the trailer brakes are set is not an acceptable method to check for bushing wear.
4. This product is designed to be operated within the free rotation limits of the coupling to drawbar eye connection. It is the responsibility of the vehicle designer/end user to ensure that these limits are not exceeded (do not bind-up/jackknife).
5. WARNING: Prior to towing, make certain that adequately rated safety chains have been properly connected.
6. Never weld on any Premier part in order to repair damaged or worn areas. Field and/or shop weld repairs are inadequate and may further weaken the hinge assembly.

- Never attempt weld repair of damaged or worn components
- Clean and inspect hinge assemblies for damage or excessive wear before each and every use
- All welds should be performed by a certified welder skilled in structural welding practices
- The mounting structure the hinges are welded to must be of sufficient strength to withstand load ratings of hinges
- Do not bind-up (Jackknife) any application as stresses can cause damage to products or components, resulting in failure and detachment of the trailer while in use

MODEL 440/440A & 455/455A HINGE ASSEMBLIES

Welding Procedures

WELDING PROCEDURE SPECIFICATION (WPS) Yes (X) PREQUALIFIED (X) QUALIFIED BY TESTING (X) or PROCEDURE QUALIFICATION RECORD (PQR) Yes (X)

GMAW		Identification #: PMEM-1	
Revision 0		Date: 2/1/00	By: PI
Company Name: Premier Manufacturing Co.		Authorized By:	Date:
Welding Process(es): GMAW		Type: Manual	Semi-Automatic: (X)
Supporting PQR No. (s): N/A Prequalified		Machine:	Automatic:
JOINT DESIGN USED		POSITION	
Type: All Fillets, Butts (See Attached)		Position of Groove: 1G, 2G	
Single (X) Double Weld (X)		Vertical Progression: Up (X) Down ()	
Backing: Yes (X) No (X)		ELECTRICAL CHARACTERISTICS	
Backing Material: M1-P1-S1, Group 1 & 2		Transfer Mode (GMAW) short-circuiting ()	
Root Opening: ---		Globular (X) Spray (X)	
Root Face Dimension: ---		Current: AC () DCEP(X) DCEN () Pulsed ()	
Groove Angle: ---		Radius (J-U): ---	
Back Gouging: Yes (X) No (X) Method: Mech/Thermal		Other:	
BASE METALS		TECHNIQUE	
Material Spec.: M1-P1-S1 1026 Carbon Steel		Stringer or Weave Bead: String or Weave	
Type or Grade: Group 1 & 2		Multi-Pass or Single Pass (per side): Single, Multiple	
Thickness: Groove: 1/8" - 1 1/8" Fillet: Unlimited		Number of electrodes: Single	
Diameter (Pipe): 4" Minimum		Electrode Spacing:	
FILLER METALS		Longitudinal: ---	
AWS Specification: A5.18		Lateral: ---	
AWS Classification: E70S-1		Angle: ---	
SHIELDING		Contact Tube to Work Distance: 3/4" ± 1/8"	
Flux:		Peening: Recommended	
Gas: CO ₂		Interpass Cleaning: Mechanical	
Composition: 100%		POSTWELD HEAT TREATMENT	
Electrode-Flux (Class):		Flow Rate: 30-50 c/h	
Temp.: ---		Time: ---	
Gas Cup Size: 1/2" Dia.			
PREHEAT			
Preheat Temp.: Min.: 100°F			
Interpass Temp.: Min.: 100°F Max.: 500°F			

WELDING PROCEDURE							
Pass or Weld Layer(s)	Process	Filler Metals		Current		Volts	Travel Speed
		Class	Diam.	Type & Polarity	Amps or Wire Feed Speed		
All	GMAW	E70S-X	0.035	DCEP	190-230	22-31	13 ±1 IPM
All	GMAW	E70S-X	0.045	DCEP	280-290	27-31	13 ±1 IPM

WELDING PROCEDURE SPECIFICATION (WPS) Yes (X) PREQUALIFIED (X) QUALIFIED BY TESTING () or PROCEDURE QUALIFICATION RECORD (PQR) Yes ()

SMAW		Identification #: PMSMA-1	
Revision 0		Date: 2/1/00	By: PI
Company Name: Premier Manufacturing Co.		Authorized By:	Date:
Welding Process(es): SMAW		Type: Manual (X)	Semi-Automatic:
Supporting PQR No. (s): N/A (Pre-Qualified)		Machine:	Automatic:
JOINT DESIGN USED		POSITION	
Type: All Fillets-Butts (See Attached)		Position of Groove: All	
Single (X) Double Weld (X)		Vertical Progression: Up (X) Down ()	
Backing: Yes (X) No (X)		ELECTRICAL CHARACTERISTICS	
Backing Material: M1-P1-S1, Group 1 & 2		Transfer Mode (GMAW) short-circuiting ()	
Root Opening: ---		Globular () Spray ()	
Root Face Dimension: ---		Current AC () DCEP (X) DCEN () Pulsed ()	
Groove Angle: ---		Radius (J-U): ---	
Back Gouging: Yes (X) No (X) Method: Mech/Thermal		Other:	
BASE METALS		TECHNIQUE	
Material Spec.: M1-P1-S1 1026 Carbon Steel		Stringer or Weave Bead: String and Weave	
Type or Grade: Group 1 and 2		Multi-Pass or Single Pass (per side): Multiple/Single	
Thickness: Groove: 1/8"-1 1/2" Fillet: Unlimited		Number of electrodes: Single	
Diameter (Pipe): 4" Minimum		Electrode Spacing:	
FILLER METALS		Longitudinal: N/A	
AWS Specification: A5.1-A5.5		Lateral: N/A	
AWS Classification: E7018		Angle: N/A	
SHIELDING		Contact Tube to Work Distance: N/A	
Flux:		Peening: Recommended	
Gas: N/A		Interpass Cleaning: Mechanical Only	
Composition: N/A		POSTWELD HEAT TREATMENT	
Electrode-Flux (Class):		Flow Rate: N/A	
Temp.: N/A		Time: N/A	
Gas Cup Size: N/A			
PREHEAT			
Preheat Temp.: Min.: 100°F			
Interpass Temp.: Min.: 100°F Max.: 500°F			

WELDING PROCEDURE							
Pass or Weld Layer(s)	Process	Filler Metals		Current		Volts	Travel Speed
		Class	Diam.	Type & Polarity	(Amps) or Wire Feed Speed		
All	SMAW	E7018	3/32"	DCEP	70-110	19-22	As Required
All	SMAW	E7018	1/8"	DCEP	90-150	26-24	
All	SMAW	E7018	5/32"	DCEP	120-90	26-24	

WELDING PROCEDURE SPECIFICATION (WPS) Yes (X) PREQUALIFIED (X) QUALIFIED BY TESTING () or PROCEDURE QUALIFICATION RECORD (PQR) Yes ()

FCAW		Identification #: PMFC-1	
Revision 0		Date: 2/1/00	By: PI
Company Name: Premier Manufacturing Co.		Authorized By:	Date:
Welding Process(es): FCAW		Type: Manual (X)	Semi-Automatic:
Supporting PQR No. (s): N/A (Pre-Qualified)		Machine:	Automatic:
JOINT DESIGN USED		POSITION	
Type: All Fillets-Butts (See Attached)		Position of Groove: All	
Single (X) Double Weld (X)		Vertical Progression: Up (X) Down ()	
Backing: Yes (X) No (X)		ELECTRICAL CHARACTERISTICS	
Backing Material: M1-P1-S1, Group 1 & 2		Transfer Mode (GMAW) short-circuiting ()	
Root Opening: ---		Globular (X) Spray (X)	
Root Face Dimension: ---		Current: AC () DCEP(X) DCEN () Pulsed ()	
Groove Angle: ---		Radius (J-U): ---	
Back Gouging: Yes (X) No (X) Method: Mech/Thermal		Other:	
BASE METALS		TECHNIQUE	
Material Spec.: M1-P1-S1 1026 Carbon Steel		Stringer or Weave Bead: String and Weave	
Type or Grade: Group 1 and 2		Multi-Pass or Single Pass (per side): Multiple/Single	
Thickness: Groove: 1/8"-1 1/2" Fillet: Unlimited		Number of electrodes: Single	
Diameter (Pipe): 4" Minimum		Electrode Spacing:	
FILLER METALS		Longitudinal: N/A	
AWS Specification: A5.20		Lateral: N/A	
AWS Classification: E70T-1/E71T-1		Angle: N/A	
SHIELDING		Contact Tube to Work Distance: 3/4" ± 1/4"	
Flux:		Peening: Recommended	
Gas: CO ₂		Interpass Cleaning: Mechanical Only	
Composition: 100%		POSTWELD HEAT TREATMENT	
Electrode-Flux (Class):		Flow Rate: 30-50 c/h	
Temp.: N/A		Time: N/A	
Gas Cup Size: 1/2" Dia. Min.			
PREHEAT			
Preheat Temp.: Min.: 100°F			
Interpass Temp.: Min.: 100°F Max.: 500°F			

WELDING PROCEDURE							
Pass or Weld Layer(s)	Process	Filler Metals		Current		Volts	Travel Speed
		Class	Diam.	Type & Polarity	(Amps) or Wire Feed Speed		
All	FCAW	E70T-1	0.045	DCEP	180-280	24-28	As Required
All	FCAW	E71T-1	0.052	DCEP	190-300	24-29	
All	FCAW		0.068	DCEP	210-350	24-29	
All	FCAW		5/64"	DCEP	250-400	26-30	



CONTINUE TO NEXT PAGE FOR
IMPORTANT INFORMATION.



ATTENTION!

End Users must read and follow this information.

DISTRIBUTORS & OEM'S: Please ensure that your customers are made aware of the following information on this page.

1. VERIFY THAT BOTH COUPLING'S AND DRAWBAR EYE'S RATED CAPACITIES MEET YOUR APPLICATION(S) REQUIREMENTS.
2. DO NOT OVERLOAD COUPLING OR DRAWBAR EYE.
3. INSPECT COUPLING, LATCH AND DRAWBAR EYE FOR CRACKS, BENDING DAMAGE OR EXCESSIVE WEAR.
DO NOT USE IF ANY OF THESE CONDITIONS EXIST!
4. CHECK FOR GAP BETWEEN CLOSED LATCH AND TOP OF HORN OR COUPLING BALL.
DO NOT USE IF GAP IS 3/8 IN. OR MORE.
5. MAKE SURE COUPLING IS LATCHED AND THAT LATCH WILL NOT OPEN.
6. PRIOR TO USE, ALWAYS CONNECT SAFETY CHAINS OF ADEQUATE STRENGTH FOR LOAD(S) BEING TOWED.
7. DO NOT BIND-UP (JACKKNIFE) ANY APPLICATION AS STRESSES CAN CAUSE DAMAGE TO THE COUPLING, DRAWBAR EYE, OTHER COMPONENTS OR ANY COMBINATION OF THEM. JACKKNIFING MAY RESULT IN FAILURE OF PRODUCTS OR COMPONENTS, RESULTING IN DETACHMENT OF THE TRAILER WHILE IN USE.
8. DO NOT APPLY LUBRICANTS TO THE COUPLING HOOK OR DRAWBAR EYE LOOP, AS THEY CAN COVER UP POSSIBLE DAMAGE AND ACCELERATE WEAR.
9. ALWAYS ABIDE BY ALL APPLICABLE STATE AND FEDERAL REGULATIONS GOVERNING SAFE AND PROPER TRANSPORTATION.
10. NEVER STRIKE ANY OF THESE COMPONENTS WITH A HAMMER OR ANY OTHER DEVICE.
11. ALWAYS VERIFY PROPER OPERATION OF LATCHING SYSTEM AND COUPLING COMPONENTS PRIOR TO DRIVE OFF.
12. NEVER USE A COUPLING THAT YOU DO NOT FULLY UNDERSTAND HOW TO PROPERLY OPERATE AND VERIFY SECURE LATCHING OF.
13. **NEVER REPLACE ANY PART IN ANY OF PREMIER'S ASSEMBLIES WITH NON-PREMIER COMPONENTS. DOING SO WILL VOID ALL WARRANTY AND POTENTIALLY COMPROMISE THE UNIT'S INTEGRITY, WHICH COULD RESULT IN PROPERTY DAMAGE, SERIOUS INJURY, OR DEATH.**



WARNING!

This envelope contains important instructions

**AND MUST REMAIN ATTACHED TO THIS
DRAWBAR EYE.** It may be removed only by the

End User or by an Original Equipment
Manufacturer who preserves this envelope and
instructions and provides it to the end user.



PREMIER MANUFACTURING COMPANY
THE FIRST NAME IN QUALITY COUPLINGS
800-255-5387 (503)234-9202
www.premier-mfg.com

Models 440/440A & 455/455A
Hinge Assembly Installation, etc.
Revised: 01/12

WARRANTY: We warrant all Premier products to be free from defects in material or workmanship for one year. We will repair or replace, at our option, any Premier product which our examination reveals to be defective, provided that the product is returned to our factory, at Tualatin, Oregon transportation prepaid, within one year of purchase by the first retail purchaser. Our warranty does not extend to products which have been subject to misuse, neglect, improper installation, maintenance or application, nor does our warranty extend to products which have been repaired or altered outside of 3UH-PLHU-V facility unless the repair or alteration has been expressly authorized in writing by Premier. **This warranty is in lieu of all other warranties, express or implied, and excludes warranties of merchantability, fitness for a particular purpose and otherwise, and in no event will Premier be liable for incidental, special, contingent or consequential damages.**

DISCLAIMER: Although great care has been taken to ensure accurate information throughout this document, Premier Manufacturing Company must reserve the right to alter any information contained within. These changes include but are not limited to: Dimensional changes, load capacity and availability of any part or assembly.

© 2009 Premier Manufacturing Company

All rights reserved. Any reproduction of the photographic images or any other portion of this document, including but not limited to the photocopying, or retention and/or storage in a retrieval system of any kind, is strictly prohibited without prior express written permission from Premier Manufacturing Company.

